



# Alpha Microprocessors Motherboard Debug Monitor

---

## User's Guide

Order Number: EC-QHUVF-TE

**Revision/Update Information:** This is a revised document. It supersedes the *Alpha Microprocessors Motherboard Debug Monitor User's Guide*, EC-QHUVF-TE.

**Digital Equipment Corporation**  
Maynard, Massachusetts

<http://www.digital.com/semiconductor>

---

**October 1997**

While DIGITAL believes the information included in this publication is correct as of the date of publication, it is subject to change without notice.

Digital Equipment Corporation makes no representations that the use of its products in the manner described in this publication will not infringe on existing or future patent rights, nor do the descriptions contained in this publication imply the granting of licenses to make, use, or sell equipment or software in accordance with the description.

©Digital Equipment Corporation 1997. All rights reserved.  
Printed in U.S.A.

AlphaPC, DEC, DECchip, DIGITAL, DIGITAL Semiconductor, DIGITAL UNIX, Ladebug, OpenVMS, and the DIGITAL logo are trademarks of Digital Equipment Corporation.

DIGITAL Semiconductor is a Digital Equipment Corporation business.

BSD is a trademark of the University of California, Berkeley, CA.

Motorola is a registered trademark of Motorola, Inc.

Linux is a registered trademark of Croce, William R. Della, Jr.

OSF/1 is a registered trademark of Open Software Foundation, Inc.

Microsoft, MS-DOS, and Windows are registered trademarks and Windows NT is a trademark of Microsoft Corporation.

UNIX is a registered trademark in the United States and other countries licensed exclusively through X/Open Company Limited.

VxWorks is a registered trademark of Wind River Systems, Inc.

All other trademarks and registered trademarks are the property of their respective owners.

---

# Contents

## Preface

## 1 Introduction

1.1	Overview . . . . .	1-1
1.2	General Features . . . . .	1-1
1.3	Recommended Host System . . . . .	1-2

## 2 Getting Started

2.1	Overview . . . . .	2-1
2.2	System Requirements . . . . .	2-1
2.3	Configuring Your System . . . . .	2-1
2.3.1	Connecting to a Terminal . . . . .	2-1
2.3.2	Connecting to a PC . . . . .	2-2
2.3.3	Connecting from a System Running Windows NT . . . . .	2-2
2.3.4	Connecting from a System Running DIGITAL UNIX . . . . .	2-3
2.3.4.1	Connecting to a Serial Port . . . . .	2-4
2.3.4.2	Setting Up the Host System As a BOOTP Server . . . . .	2-4
2.3.4.3	Setting Up the Host System As a Ladebug Client . . . . .	2-5
2.4	Updating the Debug Monitor Firmware . . . . .	2-5
2.4.1	Updating Firmware in a Flash ROM . . . . .	2-6
2.4.2	Updating the Flash ROM from the AlphaBIOS Setup Program . . . . .	2-7
2.4.3	Updating the Flash ROM from the Windows NT ARC Firmware . . . . .	2-9
2.4.4	Updating the Flash ROM from the Debug Monitor Firmware . . . . .	2-10
2.4.5	Updating the Flash ROM from the Alpha SRM Console Firmware . . . . .	2-11
2.4.6	Running Firmware Update . . . . .	2-13
2.4.7	Updating Firmware in a UVPROM . . . . .	2-14
2.5	Switching to the Debug Monitor Firmware on Flash ROM Systems . . . . .	2-15
2.6	Debug Monitor Memory Map . . . . .	2-16
2.6.1	Stack . . . . .	2-17
2.6.2	DMA Buffers . . . . .	2-18
2.7	Downloading Files . . . . .	2-18

2.8	Execution Commands . . . . .	2-18
2.9	Resetting the Debug Monitor . . . . .	2-19

### 3 Remote Debugging

3.1	What Is a Debugger? . . . . .	3-1
3.2	What Is a Remote Debugger? . . . . .	3-1
3.3	Remote Debug Server . . . . .	3-1
3.4	Programming Guidelines . . . . .	3-2
3.4.1	The Run-Time Environment . . . . .	3-2
3.4.2	Types of Programs . . . . .	3-2
3.4.2.1	Restriction . . . . .	3-2
3.4.3	PALcode Environment . . . . .	3-3
3.5	Ladebug Command Line Options . . . . .	3-4
3.6	Building the Executable File . . . . .	3-5
3.7	Starting a Ladebug Session . . . . .	3-6

### 4 User Commands

4.1	Overview . . . . .	4-1
4.2	Using the Commands . . . . .	4-2
4.3	User Commands Quick Reference . . . . .	4-4
4.4	User Commands . . . . .	4-10
	a propos . . . . .	4-11
	arpshow . . . . .	4-12
	bcoff . . . . .	4-13
	bcon . . . . .	4-14
	beep . . . . .	4-15
	boot . . . . .	4-16
	bootadr . . . . .	4-17
	bootopt . . . . .	4-18
	bpstat . . . . .	4-20
	cb . . . . .	4-21
	cfreq . . . . .	4-22
	cl . . . . .	4-24
	compare . . . . .	4-25
	cont . . . . .	4-26
	copy . . . . .	4-27
	cq . . . . .	4-29
	creg . . . . .	4-31
	cw . . . . .	4-33
	date . . . . .	4-35
	delete . . . . .	4-36
	dis . . . . .	4-37
	dml . . . . .	4-39
	dmq . . . . .	4-40
	ebuff . . . . .	4-41

edevice . . . . .	4-42
edmp . . . . .	4-43
einit . . . . .	4-44
eml . . . . .	4-45
emq . . . . .	4-46
eprom . . . . .	4-47
ereg . . . . .	4-48
eshow . . . . .	4-50
estat . . . . .	4-51
estop . . . . .	4-52
fill . . . . .	4-53
flash . . . . .	4-55
flasherase . . . . .	4-58
flboot . . . . .	4-60
flcd . . . . .	4-61
flcopy . . . . .	4-63
fldir . . . . .	4-65
flload . . . . .	4-67
flread . . . . .	4-68
flsave . . . . .	4-70
flwrite . . . . .	4-71
fwupdate . . . . .	4-73
go . . . . .	4-74
help . . . . .	4-75
iack . . . . .	4-77
ident . . . . .	4-78
init . . . . .	4-80
jtopal . . . . .	4-81
ladebug . . . . .	4-82
load . . . . .	4-84
mces . . . . .	4-85
mcheck . . . . .	4-86
memtest . . . . .	4-88
mrb . . . . .	4-90
mrl . . . . .	4-91
mrw . . . . .	4-92
mwb . . . . .	4-93
mw1 . . . . .	4-94
mww . . . . .	4-95
netboot . . . . .	4-96
netload . . . . .	4-98
next . . . . .	4-100
pb . . . . .	4-102
pcishow . . . . .	4-104
pfreg . . . . .	4-106
pl . . . . .	4-107
pq . . . . .	4-109
prb . . . . .	4-111
preg . . . . .	4-112

prl . . . . .	4-113
prw . . . . .	4-114
pw . . . . .	4-116
pwb . . . . .	4-118
pwl . . . . .	4-119
pww . . . . .	4-120
rabox . . . . .	4-121
rb . . . . .	4-122
rbcfg . . . . .	4-123
rbctl . . . . .	4-124
rbiu . . . . .	4-125
riccsr . . . . .	4-126
rl . . . . .	4-127
rmode . . . . .	4-128
romboot . . . . .	4-131
romlist . . . . .	4-134
romload . . . . .	4-135
romverify . . . . .	4-138
rsys . . . . .	4-140
rw . . . . .	4-141
sb . . . . .	4-142
setbaud . . . . .	4-144
setty . . . . .	4-145
sl . . . . .	4-146
sq . . . . .	4-148
step . . . . .	4-150
stop . . . . .	4-152
sum . . . . .	4-153
sw . . . . .	4-154
swpipl . . . . .	4-155
sysshow . . . . .	4-156
tip . . . . .	4-157
version . . . . .	4-158
wabox . . . . .	4-159
wb . . . . .	4-160
wbcfg . . . . .	4-161
wbctl . . . . .	4-162
wbiu . . . . .	4-163
wiccsr . . . . .	4-164
wl . . . . .	4-165
wrfen . . . . .	4-166
wsys . . . . .	4-167
ww . . . . .	4-168

## A Support, Products, and Documentation

### Index

## Figures

2-1	Debug Monitor Memory Map. . . . .	2-17
-----	-----------------------------------	------

## Tables

4-1	Command Summary Table.....	4-4
-----	----------------------------	-----



---

# Preface

## Introduction

This document describes the software features of an Alpha microprocessor motherboard. The motherboard software is intended to provide software monitor and debug capabilities to customers who use an Alpha microprocessor motherboard as a development platform for creating their own Alpha microprocessor-based systems.

## Audience

This document is for anyone who develops software or hardware to be used with an Alpha microprocessor. The Alpha Microprocessors Motherboard Debug Monitor (Debug Monitor) supports the following products:

- AlphaPC 164SX Motherboard (AlphaPC 164SX)
- AlphaPC 164LX Motherboard (AlphaPC 164LX)
- AlphaPC 164 Motherboard (AlphaPC 164)
- Alpha 21164 Evaluation Board (EB164)
- AlphaPC 64 Evaluation Board (AlphaPC 64)
- Alpha 21066A Evaluation Board (EB66+)
- Alpha 21064 and Alpha 21064A PCI Evaluation Board (EB64+)
- Alpha 21066 and Alpha 21068 Evaluation Board (EB66)
- Alpha 21064 Evaluation Board (EB64)

## Content Overview

The information in this document is organized as follows:

- Chapter 1 is an introduction to the Debug Monitor.
- Chapter 2 describes how to use this Debug Monitor.
- Chapter 3 describes how to use remote debugging.
- Chapter 4 lists all Debug Monitor commands.
- Appendix A contains information about technical support services and associated documentation.

## Conventions

In this document, the term motherboard refers to the AlphaPC 164SX Motherboard, the AlphaPC 164LX Motherboard, the AlphaPC 164 Motherboard, the Alpha 21164 Evaluation Board, the AlphaPC 64 Evaluation Board, the Alpha 21066A Evaluation Board, the Alpha 21064 and Alpha 21064A PCI Evaluation Board, the Alpha 21066 and Alpha 21068 Evaluation Board, and the Alpha 21064 Evaluation Board, unless otherwise noted.

The following conventions are used in this document:

Convention	Definition
A percent sign (%)	Indicates a DIGITAL UNIX operating system command prompt.
A pound sign (#)	Indicates a DIGITAL UNIX superuser prompt and indicates that these commands are performed from the root directory level.
Square brackets ([])	Denote optional syntax.
<b>Boldface type</b>	Indicates Debug Monitor command text.
EBxxx>	Indicates a motherboard command prompt.
<i>Italic type</i>	Emphasizes important information, indicates variables in command syntax, and denotes complete titles of documents.
Monospaced type	Indicates an operating system command, a file name, or a directory path name.

All numbers are decimal unless otherwise indicated. Where there is ambiguity, numbers other than decimal have a subscript indicating their base.

## 1.1 Overview

The Alpha Microprocessors Motherboard Debug Monitor can be used to load code into the system and perform other software debug functions, such as memory read/write and instruction breakpointing. Combined with a hardware interface, the Debug Monitor can be used to write and debug software for the following:

- Device drivers for workstation and PC-type products
- Embedded control products, such as:
  - Laser printers
  - Communication engines
  - Video products

The Debug Monitor is provided with the motherboard in an industry-standard 512KB EPROM or a 1MB flash ROM. You can develop your code on a host system and load the software into the motherboard through a serial port, Ethernet port, user-supplied floppy drive, or the extra ROM socket. The full source code is provided with a free license allowing you to use and modify this code as you desire.

## 1.2 General Features

The Debug Monitor offers the ability to:

- Download files via serial and Ethernet ports, ROM socket, and user-supplied floppy drive.
- Examine and deposit the motherboard system register, CPU internal processor registers (IPRs), and I/O mapped registers.
- Examine and modify DRAM and I/O mapped memory.

## Recommended Host System

- Disassemble CPU instructions in memory.
- Transfer control to programs loaded into memory.
- Perform native debugging, including breakpoints and single stepping.
- Perform full source-level debugging using the DIGITAL Ladebug debugger (Ladebug) for DIGITAL UNIX running on a remote host that communicates through an Ethernet connection.

### 1.3 Recommended Host System

The recommended host system for software development is an Alpha system running the Windows NT or DIGITAL UNIX operating systems. Alpha hardware is the platform upon which the initial set of portable development tools is provided. The native DIGITAL UNIX and Windows NT software development tools are used in conjunction with the portable tools.

The DIGITAL UNIX operating system also supports the bootstrap protocol (BOOTP) for downloading executable images to the motherboard and Ladebug for remote debugging. The examples in this manual that pertain to a host system are based on Alpha hardware running the DIGITAL UNIX operating system.

## 2.1 Overview

This chapter describes how to set up your motherboard and host system.

## 2.2 System Requirements

The minimum configuration that you need in order to use your motherboard is a power supply and a terminal. However, to take full advantage of the motherboard, you need an Alpha host development system running the Windows NT or DIGITAL UNIX operating systems.

## 2.3 Configuring Your System

This section describes how to connect your motherboard to the following:

- A terminal
- A PC running communication software
- A system running Windows NT
- An Alpha system running DIGITAL UNIX

You need to provide a power supply for the motherboard. See your motherboard's user's manual for more information about requirements for your power supply.

### 2.3.1 Connecting to a Terminal

To connect the motherboard to a terminal, connect the terminal communication line to serial port 1 of the motherboard. For example, on the EB64, this port is on connector J12. Your terminal should be set to match the baud rate of the motherboard. The default speed of the EB64 serial port is 9600 baud.

## Configuring Your System

After the terminal and the motherboard are connected and the motherboard is powered on, the terminal screen should display the banner and prompt. For example:

```
DECchip 21064 Evaluation Board (EB64) Debug Monitor
Version:  Tue May 04 16:55:54 EDT 1993
Bootadr: 0x100000, memSize:  0x2000000 (32MB)

EB64>
```

**Note:** Using a terminal in this manner is the most effective way to quickly verify that your motherboard was not damaged during shipping. You can use the ROM socket to load and boot software through a compatible ROM. However, to download a file, you need a system running terminal emulation software that has the capability of performing text dumps through the serial connection or through an Ethernet connection to a host system that supports the BOOTP protocol.

### 2.3.2 Connecting to a PC

Communication (terminal emulation) software running on a PC can also be used to communicate with the motherboard. To connect the motherboard to a PC, connect the terminal communication line to serial port 1 of the motherboard as described for the terminal.

### 2.3.3 Connecting from a System Running Windows NT

A system running the Windows NT operating system supports serial communication with the motherboard. To configure a COM port, follow these steps:

1. Choose the `Program Manager` icon.
2. Choose the `Accessories` icon.
3. Choose the `Terminal` icon.
4. Set the following terminal characteristics:

Terminal Setting	Value
Data bits	8 bit
Transmit/receive speed	9600 baud
Character format	No parity
Stop bits	1

Save these settings in a file. For example, settings for the EB64 could be saved in a file called `eb64.trm`.

For consistency, all examples and command descriptions assume that the motherboard serial port 1 is connected to COM1.

### 2.3.4 Connecting from a System Running DIGITAL UNIX

DIGITAL UNIX supports serial communications and Ethernet communications with the motherboard.

An Alpha system running the DIGITAL UNIX operating system supports serial communication through the following two ports that can be connected to the motherboard:

- `/dev/tty00`
- `/dev/tty01`

For consistency, all examples and command descriptions assume that the motherboard serial port 1 is connected to port `/dev/tty00`.

To enable these ports for use with the motherboard, follow these steps:

1. Log in as superuser.
2. Modify the following two files:

```
/etc/remote  
/etc/inittab
```

- a. Add the following two lines to the `/etc/remote` file. These lines define a device to connect to when using the DIGITAL UNIX `tip` command.

```
port_name0:dv=/dev/tty00:br#9600:pa=none:  
port_name1:dv=/dev/tty01:br#9600:pa=none:
```

The `port_name` refers to an arbitrary name that you assign to that port.

- b. Modify the `/etc/inittab` file to disable logins on the two serial communication ports by setting the third field to `off`. For example, modify the `tty00` and `tty01` lines as follows:

```
tty00:23:off:/usr/sbin/getty /dev/tty00 9600  
tty01:23:off:/usr/sbin/getty /dev/tty01 9600
```

3. Reboot the system or issue the following command to ensure that the modified files take effect:

```
# /sbin/init q
```

# Configuring Your System

## 2.3.4.1 Connecting to a Serial Port

After you modify the `/etc/remote` and `/etc/inittab` files, you can connect to the serial port under the DIGITAL UNIX operating system using the DIGITAL UNIX `tip` command. If the connection is successful, the motherboard prompt displays, and you are ready to use the Debug Monitor **load** or **boot** commands to download your file. For example,

```
% tip port_name0
EB64> load
Send File now ...
```

Type `~>` to cause the DIGITAL UNIX `tip` command to send the file to the motherboard.

## 2.3.4.2 Setting Up the Host System As a BOOTP Server

The bootstrap protocol (BOOTP) needs to be defined so that the commands **netload** and **netboot** work correctly. To set up a DIGITAL UNIX system as a BOOTP server, follow these steps:

1. Modify the `/etc/inetd.conf` file. This file enables both the BOOTP and the TFTP daemons. The TFTP daemon is required by the BOOTP daemon.
  - a. Add the following line to specify the directories that can be accessed by the TFTP daemon:

```
tftp dgram udp wait root /usr/sbin/tftpd tftpd /directory1
/directory2
```

If no directory is specified, all files with public access can be accessed by the TFTP daemon.

- b. To start the BOOTP daemon, enter the following line:

```
bootps dgram udp wait root /usr/sbin/bootpd bootpd -d -d -d
```
2. If BOOTP is already running on your system, you want to stop it. To stop BOOTP, enter the following commands:

```
# ps uax | grep bootpd
# kill -KILL process_id_number
# ps uax | grep inetd
# kill -HUP process_id_number
```

3. To restart BOOTP, enter the following command:

```
# /sbin/init q
```

The changes made to the `/etc/inetd.conf` file will now take effect.



## Updating the Debug Monitor Firmware

4. Modify the `/etc/bootptab` file to specify the Ethernet hardware address of the motherboard and the IP address assigned to that node. Contact your network administrator to obtain an IP address. Refer to the literature supplied with your Ethernet card to obtain information about the hardware address. If the hardware address is accessible through software, you can use the **init** command to display it. For example, the following lines modify this file for the EB64:

```
remote_system_name0:ht=ethernet:ha=BA9876543210:ip=16.123.45.67:\
:hd=/directory1:bf=filename:vm=auto:
```

BOOTP checks this file to see if it has changed each time it receives a request. If it has changed, the new file is read. The *directory* and *filename* are the defaults for the **netload** and **netboot** commands. If no argument is specified with either command, the file loaded is `/directory1/filename`.

### Verify the BOOTP Server

To verify that the BOOTP server has been set up properly, you can look at the `daemon.log` file. This file shows directories accessed for the **netload** or **netboot** commands.

```
# tail -f /var/adm/sylog.dated/dated_dir/daemon.log
```

The following example displays a boot request from an example daemon log file:

```
May 5 10:40:28 eval bootpd[328]:request from hardware address BA9876543210
May 5 10:40:28 eval bootpd[328]:found: eb64 (BA9876543210) at (16.123.45.67)
May 5 10:40:28 eval bootpd[328]:file /users/eval/boot/size.eb64 not found
May 5 10:40:28 eval bootpd[328]:vendor magic field is 0.0.0.0
May 5 10:40:28 eval bootpd[328]:sending RFC1048-style reply
```

You can refer to the DIGITAL UNIX man pages for more information about `bootp`, `bootpd`, `tftp`, `tftpd`, `inet`, `inetd`, and `init`.

### 2.3.4.3 Setting Up the Host System As a Ladebug Client

The Debug Monitor supports remote debugging for DIGITAL UNIX host systems with Ladebug. The Ladebug software does not accept numeric internet addresses. You can give your motherboard an internet name in the `/etc/hosts` file. In the `/etc/hosts` file, the format is the internet protocol (IP) address followed by the host system name. For example:

```
12.345.67.89    remote_system_name0
```

## 2.4 Updating the Debug Monitor Firmware

Depending on the type of motherboard, the firmware is stored in either a flash ROM or a UV PROM.

## Updating the Debug Monitor Firmware

For the AlphaPC 164SX, AlphaPC 164LX, AlphaPC 164, EB164, AlphaPC 64, and EB66+, you update the Debug Monitor firmware in the flash ROM.

The EB64+, EB66, and EB64 have a UVPR0M. A new UVPR0M containing the Debug Monitor firmware needs to be obtained and installed on these motherboards.

After the Debug Monitor firmware has been installed, the motherboard system is restarted to activate the new firmware.

Use the following table to determine the update procedure for your motherboard.

To update firmware on an...	See this section...
AlphaPC 164SX AlphaPC 164LX AlphaPC 164 EB164 Alpha PC 64 EB66+	Updating Firmware in a Flash ROM
EB64+ EB66 EB64	Updating Firmware in a UVPR0M

### 2.4.1 Updating Firmware in a Flash ROM

The AlphaBIOS setup program is used to update the firmware in a flash ROM on the AlphaPC 164SX and the AlphaPC 164LX. The firmware update utility is used to add or update the firmware in a flash ROM on the AlphaPC 164, EB164, AlphaPC 64, and EB66+. Depending on which firmware you are using, this utility can be invoked from a diskette or from a compact disc.

To update the flash ROM, the update enable/disable jumper must be in the enable position, which is the default. See your motherboard's user's manual for more information about jumper positions.

## Updating the Debug Monitor Firmware

Use the following table to determine the update procedure for your motherboard.

System	If your system is running...	Then see this section...
AlphaPC 164SX AlphaPC 164LX	Windows NT firmware	Updating the Flash ROM from the AlphaBIOS Setup Program
AlphaPC 164 EB164 AlphaPC 64 EB66+	Windows NT firmware	Updating the Flash ROM from Windows NT ARC Firmware
AlphaPC 164SX AlphaPC 164LX AlphaPC 164 EB164 AlphaPC 64 EB66+	Debug Monitor firmware	Updating the Flash ROM from the Debug Monitor Firmware
AlphaPC 164SX AlphaPC 164LX AlphaPC 164 EB164 AlphaPC 64 EB66+	Alpha SRM Console firmware	Updating the Flash ROM from the Alpha SRM Console Firmware

### 2.4.2 Updating the Flash ROM from the AlphaBIOS Setup Program

This section describes how to update the flash ROM from the AlphaBIOS setup program on the AlphaPC 164SX and the AlphaPC 164LX.

#### AlphaBIOS Conventions

AlphaBIOS uses universally accepted keys and key combinations for navigating the interface and selecting items. If you are familiar with MS-DOS or Microsoft Windows keyboard conventions, navigating AlphaBIOS is simple. Use the keys and key combinations shown in the following table when navigating and selecting items in AlphaBIOS.

## Updating the Debug Monitor Firmware

Key or Key Combination	Description
Tab	Move highlight forward between fields of a dialog.
Shift + Tab	Move highlight backwards between fields of a dialog.
↓ or ↑	Move highlight within a menu, or cycle through available field values in a dialog window.
Alt + ↓	Drop down a menu of choices from a drop-down listbox. A drop-down listbox can be recognized by the symbol ↓.
Home	Move to the beginning of a text entry field.
End	Move to the end of a text entry field.
← or →	Move to the left or right in a text entry field.
Esc	Discard changes and back up to previous screen.

Two levels of keyboard help are available:

- Press **F1** once to display explanations of the keystrokes available for the *currently displayed* part of AlphaBIOS.
- Press **F1** twice to display explanations of the keystrokes available for navigating throughout AlphaBIOS.

### Running the AlphaBIOS Setup Program

To invoke and run the AlphaBIOS Setup program, follow this procedure:

1. When you power up or reset your system, the AlphaBIOS boot screen with the system logo is displayed. Press **F2** to start the AlphaBIOS Setup program.
2. Insert the diskette or CD-ROM that contains the Debug Monitor firmware image into the appropriate drive.
3. From the AlphaBIOS Setup screen, select the AlphaBIOS Upgrade... option by using the arrow or Tab keys. Press **Enter** to begin installing the Debug Monitor firmware image.

## Updating the Debug Monitor Firmware

4. The AlphaBIOS Upgrade Options screen is displayed. If more than one image is found, the new image's name is displayed. If the name of the new image is *not* Debug Monitor, use the down arrow key to cycle through the available field values until Debug Monitor is displayed. Press **Enter** to continue the installation.
5. An AlphaBIOS screen warning you that you have selected to switch the operating system is displayed. Press **Enter** to continue the installation.
6. The AlphaBIOS Upgrade Debug Monitor screen is displayed. Press **F10** to continue the installation.
7. The AlphaBIOS Upgrade Complete screen is displayed. To load the Debug Monitor, power cycle the system.

### 2.4.3 Updating the Flash ROM from the Windows NT ARC Firmware

The firmware update utility is used to update the firmware in a flash ROM on the AlphaPC 164, EB164, AlphaPC 64, and EB66+. Depending on the version of firmware that you have in your motherboard, this utility can be invoked from a diskette or from a compact disc.

**Note:** If your motherboard has a version of firmware prior to Version 4.42, you *must* use a diskette to invoke the firmware update utility. If your motherboard has a firmware version of 4.42 or higher, you may invoke the firmware update utility from either a diskette or a compact disc.

The firmware update utility is provided only on a compact disc; a diskette is not provided. If a firmware update diskette is required, see the *Alpha Motherboards Software Developer's Kit and Firmware Update Read Me First* for information about how to create a firmware update diskette.

#### Windows NT ARC Firmware Conventions

The currently selected option in a Windows NT ARC firmware menu is highlighted. To select and choose different options in the menus, use the following keys.

Key	Description
Arrow	The arrow keys are used to select different options.
Enter	The Enter key is used to choose the highlighted option.
Esc	The Esc (escape) key is used to close a menu or cancel an operation.

## Updating the Debug Monitor Firmware

When you power up your motherboard system, the firmware displays a blue screen on the monitor and initializes the firmware drivers. If autoboot is enabled, cancel it by pressing the Esc key before the timeout period expires. This allows you to interact with the firmware.

### Starting the Firmware Update Utility

To invoke the firmware update utility to update the firmware in a flash ROM, follow this procedure:

1. Start the firmware update utility from a compact disc or a diskette:
  - Compact disc — If you are using firmware Version 4.42 or higher and you want to run the firmware update utility from a compact disc, insert the Alpha SDK and firmware update compact disc into the CD-ROM drive.
  - Diskette — If you are using firmware prior to Version 4.42 or if you want to start the firmware update utility from a diskette, insert the diskette that you have created into drive A and verify that the CD-ROM drive does not contain a compact disc.

The firmware update utility is provided only on a compact disc; a diskette is not provided. See the *Alpha Motherboards Software Developer's Kit and Firmware Update Read Me First* for information about how to create a firmware update diskette.

2. Restart your motherboard system.
3. From the Boot menu, choose **Supplementary menu...**
4. From the Supplementary menu, choose **Install new firmware...**

**Note:** The firmware update utility will reinitialize some system components; it may appear as if your system is restarting.

5. Proceed to Section 2.4.6.

### 2.4.4 Updating the Flash ROM from the Debug Monitor Firmware

The firmware update utility is used to update the firmware in a flash ROM. This utility can be invoked by the Debug Monitor firmware only from a diskette. The firmware update utility is provided only on a compact disc; a diskette is not provided. See the *Alpha Motherboards Software Developer's Kit and Firmware Update Read Me First* for information about how to create a firmware update diskette.

# Updating the Debug Monitor Firmware

## Starting the Firmware Update Utility

To start the firmware update utility from the firmware update diskette you created, follow this procedure:

1. Insert the firmware update diskette into drive A.
2. At the Debug Monitor prompt, enter the following command:

```
EBxxx> fwupdate
```

**Notes:** Debug Monitor firmware versions prior to V2.0 do not recognize the `fwupdate` command. For versions prior to V2.0, enter the following command at the Debug Monitor prompt:

```
EBxxx> flboot fwupdate.exe 900000
```

The firmware update utility will reinitialize some system components; it may appear as if your system is restarting.

3. If updating the firmware on the AlphaPC 164SX or the AlphaPC 164LX, go to Section 2.4.2. If updating the firmware on any other motherboard, proceed to Section 2.4.6.

## 2.4.5 Updating the Flash ROM from the Alpha SRM Console Firmware

The firmware update utility is used to update the firmware in a flash ROM. This utility can be invoked by the Alpha SRM Console firmware from either a compact disc or a diskette. The firmware update utility is provided only on a compact disc; a diskette is not provided. To invoke the firmware update utility from a diskette, see the *Alpha Motherboards Software Developer's Kit and Firmware Update Read Me First* for information about how to create a firmware update diskette.

The following procedures describe two methods for invoking the firmware update utility to update the firmware in the flash ROM.

### Starting the Firmware Update Utility from a Compact Disc

To invoke the firmware update utility from a compact disc, follow this procedure:

1. Insert the Alpha SDK and firmware update compact disc into the CD-ROM drive.
2. Enter the following command to determine the unit number of the drive for your CD-ROM device:

```
>>> show dev
```

# Updating the Debug Monitor Firmware

A display appears showing information about the devices on your system. In the following example, DKA400 is the CD-ROM device:

```
dka0.0.0.9.0          DKA0          RZ26L      440C
dka400.4.0.9.0       DKA400        RRD43      1084
dva0.0.0.0.1         DVA0
ewa0.0.0.7.0         EWA0          08-00-2B-E2-B1-08
pka0.7.0.9.0         PKA0          SCSI Bus ID 7
>>>
```

The numbers in the middle column are the unit numbers assigned to each drive on your system, where:

- The letters DK refer to a SCSI CD-ROM or disk device.
  - The third letter (A, B, C, D, or E) refers to the SCSI bus designation. (Refer to the hardware owner's guide for more details.)
  - The numbers refer to the drive number.
3. Enter the `boot` command with the following syntax to boot from a compact disc:

```
>>> boot -fl 0,a0 unit-number
```

For example, to boot the system from CD-ROM drive number 4, enter:

```
>>> boot -fl 0,a0 dka400
```

The following prompt appears for the bootfile path:

```
>>> BOOTFILE:
```

4. Use the following table to determine the path that corresponds to the firmware update utility for your motherboard.

If you have an...	Enter this path...
AlphaPC 164SX	[update.sx164]fwupdate.exe
AlphaPC 164LX	[update.lx164]fwupdate.exe
AlphaPC 164	[update.pc164]fwupdate.exe
EB164	[update.eb164]fwupdate.exe
AlphaPC 64	[update.pc64]fwupdate.exe
EB66+	[update.eb66p]fwupdate.exe

**Note:** The firmware update utility will reinitialize some system components; it may appear as if your system is restarting.



## Updating the Debug Monitor Firmware

5. If updating the firmware on the AlphaPC 164SX or the AlphaPC 164LX, go to Section 2.4.2. If updating the firmware on any other motherboard, proceed to Section 2.4.6.

### Starting the Firmware Update Utility from a Diskette

The firmware update utility is provided only on a compact disc; a diskette is not provided. See the *Alpha Motherboards Software Developer's Kit and Firmware Update Read Me First* for information about how to create a firmware update diskette.

To start the firmware update utility from a firmware update diskette that you have created, follow this procedure:

1. Insert the firmware update diskette into drive A.
2. At the Alpha SRM Console prompt, enter the following command:

```
>>> fwupdate
```

**Notes:** Alpha SRM Console versions prior to V4.4–1 do not recognize the `fwupdate` command. For versions prior to V4.4–1, enter the following commands at the Alpha SRM Console prompt:

```
>>> cat fat:fwupdate.exe/dva0 > pmem: 900000  
>>> stop -drivers  
>>> jtopal 900000
```

The firmware update utility will reinitialize some system components; it may appear as if your system is restarting.

3. If updating the firmware on the AlphaPC 164SX or the AlphaPC 164LX, go to Section 2.4.2. If updating the firmware on any other motherboard, proceed to Section 2.4.6.

### 2.4.6 Running Firmware Update

To run the firmware update utility, follow this procedure:

1. If you have an AlphaPC 64, an EB164, or an EB66+, you must enable the Advanced menu to run the firmware update utility. To enable the Advanced menu, observe the initialization messages displayed on the terminal attached to

## Updating the Debug Monitor Firmware

the COM1 serial port or on the graphics display unit after starting the firmware update utility. When the message `Initializing Flash Driver` is displayed, press the A key to enable the Advanced menu.

For all other systems, proceed to step 2.

2. Choose whichever selection appears:

### **Update Debug Monitor**

### **Update Firmware**

3. When prompted to continue the update, choose **Yes**. If the console selection does not match the firmware you flashed, you will be prompted to update the console selection.
4. If you are prompted to update the console selection, use the arrow keys to choose **Yes**.
5. When the update has completed, restart your motherboard system.

## 2.4.7 Updating Firmware in a UVPROM

The Debug Monitor firmware is provided only on a compact disc; a UVPROM is not provided. To program your own UVPROM, see the *Alpha Motherboards Software Developer's Kit and Firmware Update Read Me First* to locate the .rom file or the .sr file on the Alpha SDK and firmware update compact disc. The .rom file is the actual binary image that resides in the UVPROM. The .sr file is the .rom file translated into Motorola S-record format.

### **Replacing the UVPROM**

To update the firmware on a motherboard after you have a programmed UVPROM, follow this procedure:

1. Turn off the power for the motherboard system.
2. Locate and remove one of the UVPROMs from the motherboard, noting the correct orientation of the UVPROM.
3. Insert the Debug Monitor firmware UVPROM, using the correct orientation.
4. Select the Debug Monitor firmware UVPROM device with the UVPROM select jumper, as described in the motherboard's user's manual.
5. Turn on the power for the motherboard system.
6. Observe the Debug Monitor prompt on the terminal attached to the COM1 serial port or on the graphics display unit.

## Switching to the Debug Monitor Firmware on Flash ROM Systems

**Note:** For versions of the Debug Monitor firmware prior to V2.0, the prompt will be displayed only on the terminal attached to the COM1 serial port.

### 2.5 Switching to the Debug Monitor Firmware on Flash ROM Systems

This section describes how to switch to the Debug Monitor firmware from either the Windows NT ARC firmware or the Alpha SRM Console firmware on the EB164, AlphaPC 64, EB66+, and EB64+.

**Note:** Except for the AlphaPC 64, the AlphaPC motherboards support only one firmware in the flash ROM, thus, you cannot switch to the Debug Monitor firmware from AlphaBIOS, Windows NT ARC firmware, or Alpha SRM Console firmware. You must reprogram the flash ROM if you wish to run the Debug Monitor firmware instead of the Windows NT firmware or Alpha SRM Console firmware.

#### Switching from Windows NT ARC Firmware

If your Windows NT ARC firmware is prior to Version 4.42, see your motherboard's user's manual on how to set the Boot Option jumper to switch to the Debug Monitor firmware from the Windows NT ARC firmware.

If your Windows NT ARC firmware is Version 4.42 or higher, use the following procedure to switch to the Debug Monitor firmware from the Windows NT ARC firmware:

1. From the Boot menu, choose **Supplementary menu...**
2. From the Supplementary menu, choose **Set up the system...**
3. From the Setup menu, choose **Machine specific setup...**
4. From the Machine specific setup menu, choose **Switch to Debug Monitor.**
5. Restart your motherboard system.
6. Observe the Debug Monitor prompt on the terminal attached to the COM1 serial port or on the graphics display unit.

## Debug Monitor Memory Map

### Switching from Alpha SRM Console Firmware

To switch to the Debug Monitor firmware from the Alpha SRM Console firmware, follow this procedure:

1. At the Alpha SRM Console prompt, enter the following command:  

```
>>> deposit -b toy:3f 0
```
2. Restart your motherboard system.
3. Observe the Debug Monitor prompt on the terminal attached to the COM1 serial port or on the graphics display unit.


**Note:** For versions of the Debug Monitor firmware prior to V2.0, the prompt will be displayed only on the terminal attached to the COM1 serial port.

## 2.6 Debug Monitor Memory Map

The Debug Monitor image is loaded from the system ROM into memory at physical address 0 by the SROM initialization code. At startup, the Debug Monitor determines the amount of memory present in the motherboard based on parameters that are passed in from the SROM initialization code. One of these parameters determines the top of main memory. Refer to your motherboard's user's manual for more information about the SROM initialization code and supported memory configurations.

Figure 2–1 shows the basic outline for the Debug Monitor memory map.

**Figure 2–1 Debug Monitor Memory Map**



FM-05670.A14

The Debug Monitor image consists of PALcode at physical address 0 and the Debug Monitor kernel at physical address  $10000_{16}$ . After loading the image into memory, the SROM initialization code begins execution of the image in PALmode at the PALcode base address.

The PALcode used in the Debug Monitor was designed to support DIGITAL UNIX (formerly DEC OSF/1) and was later adapted to the Debug Monitor. Refer to the *Alpha AXP Architecture Reference Manual* and the *PALcode for Alpha Microprocessors System Design Guide* for more information about DIGITAL UNIX PALcode.

## 2.6.1 Stack

PALcode starts execution of the Debug Monitor kernel at physical address  $10000_{16}$ . Upon entry to the Debug Monitor kernel, the Debug Monitor establishes the initial stack pointer at the first 8KB boundary below the top of main memory. From there the stack grows downward.

# Downloading Files

## 2.6.2 DMA Buffers

Various devices used with the motherboard require direct memory access (DMA). The device drivers provided in the Debug Monitor for these devices are designed to perform their DMA within a 1MB range starting at 1 megabyte (physical address  $100000_{16}$ ). At startup, the Debug Monitor initializes the I/O subsystem with DMA windows that include this range. The device drivers included with the Debug Monitor that require DMA are the Ethernet and diskette drivers. Although the **ebuff** command can be used to change the base of the Ethernet buffers, the buffers must remain within this 1MB window.

## 2.7 Downloading Files

The motherboard supports loading files into memory from a serial port, the Ethernet, and a diskette. The user can either load the file into memory, or load and execute the file in a single step. The following table shows the commands for the specific I/O devices. See Chapter 4 for more details about these commands.

I/O Device	Use this command to load into memory...	Use this command to load into memory and execute...
ROM socket	romload	romboot
Serial port	load	boot
Ethernet	netload	netboot
Diskette	flload	flboot

The default boot address (**bootadr**) is  $300000_{16}$ . However, you can change the default boot address with the **bootadr** command. The new setting is then stored in the battery-backed RAM.

## 2.8 Execution Commands

After your program is loaded, you are ready to execute it. If the command loads and executes a program, you may want to re-execute the program during the motherboard session. The Debug Monitor has two commands to execute programs: **go** and **jtopal**. See Chapter 4 for more details about these commands.

### 2.9 Resetting the Debug Monitor

If the software hangs the motherboard, then the hardware reset on the board can be used to reset to the Debug Monitor command line. For information about connecting the reset signals, see your motherboard's user's manual.





---

## Remote Debugging

The Debug Monitor supports remote debugging for DIGITAL UNIX host systems with Ladebug. The Ladebug software provides the full source-level debugging capabilities of most programs that run on the motherboard, including the Debug Monitor.

This chapter describes some debugging hints for use with the Debug Monitor and the remote debugger. This chapter also describes the guidelines for writing programs that allow you to take full advantage of remote debugging.

### 3.1 What Is a Debugger?

A debugger is a tool that helps you locate run-time programming errors or bugs. You use the debugger on executable programs created when a program has been compiled and linked successfully.

### 3.2 What Is a Remote Debugger?

A remote debugger is a tool that helps you locate run-time programming errors or bugs in a program running on a remote system. The remote system can be a system that cannot support a full programming environment by itself. You use a remote debugger on executable programs compiled and linked for the remote system.

### 3.3 Remote Debug Server

The Debug Monitor's remote debug server (the part of the monitor that communicates with Ladebug) uses interrupts and an Ethernet device. Interrupts are used by the Debug Monitor to poll the Ethernet device for messages from Ladebug. Any program that changes the interrupt handler must instruct the debug server when to poll the Ethernet.

## Programming Guidelines

### 3.4 Programming Guidelines

The following sections describe the programming guidelines for remote debugging.

#### 3.4.1 The Run-Time Environment

When a program is started by the Debug Monitor's **go** command, it is started at the appropriate IPL to enable real-time clock interrupts (usually IPL 4). If a program *does not* install its own interrupt handler, then the Debug Monitor will handle all interrupts. If a program *does* install its own interrupt handler using the Write System Entry Address PAL call, then it must be prepared to handle all interrupts as described in the following sections. When a program completes normally, the Debug Monitor reinstalls its own interrupt handler.

#### 3.4.2 Types of Programs

For the purposes of this chapter, programs may be classified into the following three types:

- Programs that do not use the Ethernet or do not include their own interrupt handler.
- Programs that do not use the Ethernet but do include their own interrupt handler.
- Programs that use the Ethernet.

##### 3.4.2.1 Restriction

There is only one restriction for programs that do not use the Ethernet and that use the Debug Monitor interrupt handler. Do *not* disable the real-time clock interrupt and the Ethernet interrupts for long periods.

Long delays may cause Ladebug to behave as if there is a problem with the Ethernet link to the target. If network delays are insignificant, Ladebug will tolerate periods of up to ten seconds with interrupts disabled, although it will normally warn the user of possible network problems if interrupts are disabled for more than a second.

Ethernet interrupts are disabled at IPL 3 or more, and real-time clock interrupts are disabled at IPL 5 or more. Writing to the control registers of the Ethernet device or to the real-time clock can also disable the interrupts. It is possible to set breakpoints or to single step uninterruptible code. There is no restriction on the time that can be spent at the breakpoint.

Programs that define or install their own interrupt handler must ensure that the Debug Monitor polls the Ethernet device often enough to receive all the messages sent to it by Ladebug. An easy way to do this is to use the `ladbx_poll` function. When this function is called, the following occurs:

- All frames that have been received on the Ethernet device are read.
- All remote debug frames are processed and acted upon.
- Any Ethernet interrupt is cleared.

The `ladbx_poll` function is a void function that takes no arguments. It must be called often enough to allow the Debug Monitor to respond promptly to all received Ethernet frames. To ensure that this function gets called at the proper time, enable either Ethernet or timer interrupts (or both) and call it every time an interrupt occurs.

Programs cannot share an Ethernet device with the Debug Monitor. The Debug Monitor can drive a selection of different types of Ethernet devices on ISA or PCI cards, and an individual Ethernet device can be selected with the Debug Monitor **edevic** command.

### 3.4.3 PALcode Environment

Most programs will be able to use the DIGITAL UNIX compatible PALcode included with the Debug Monitor; however, for the programs that install their own PALcode, the following guidelines must be followed:

- For remote debug to work, the following DIGITAL UNIX PALcode calls must be implemented according to the interface described in the DEC OSF/1 section of the *Alpha AXP Architecture Reference Manual*.

IMB  
RDUSP  
RTI  
WPIPL  
WRENT

- The interface to the system must conform to the standards described in the DEC OSF/1 section of the *Alpha AXP Architecture Reference Manual*.

## Ladebug Command Line Options

- The debug server uses the DBGSTOP PAL call to implement breakpoints. The program must contain an identical implementation of the DBGSTOP PAL call.  
This PAL call, rather than the BPT PAL call, is used because complex programs (such as operating systems) are likely to reset the EntIF system entry point during initialization.
- The program reset PALcode routine must preserve the address of the debug entry point through the installation of the new PALcode. For the motherboard PALcode, this address is held in the PAL temporary register with symbolic name ptEntDbg. The user-defined PALcode must also either preserve the address of the interrupt entry point (ptEntInt) or set the IPL to a level that prevents all interrupts until the program sets up its own interrupt handler containing a call to `ladbx_poll`.

### 3.5 Ladebug Command Line Options

Versions 1.3 or later of Ladebug provide the following command line options to support remote debugging.

<i>(Sheet 1 of 2)</i>	
<b>Command Line Option</b>	<b>Description</b>
<code>-rn <i>node_name</i></code>	Specifies IP node name of the target node. Required for remote debug. No default.
<code>-pid <i>process_id</i></code>	Specifies the process id of the process to be debugged. The Ladebug software debugs a running process rather than loading a new process.
<code>-rfn <i>arbitrary string</i></code>	Specifies the file name (or other identifier) of the image to be loaded on a remote system. Defaults to the local object file name. Passed to the remote system uninterrupted. Will often have to be quoted to avoid shell command line interpretation on the local system. Can be used only with <code>-rn</code> ; do not combine with <code>-pid</code> .

(Sheet 2 of 2)

Command Line Option	Description
-rinsist	Connects to a running remote process using the connect insist protocol message instead of the connect protocol message. This option functions as a request to the server to connect to the client even if some other client is already connected. (The previously connected client is disconnected.) Use only with -rn and -pid.
-rp <i>debug protocol name</i>	Specifies the remote debug protocol to be used. The valid value and default, is <code>ladebug_preemptive</code> .
-rt <i>transport protocol name</i>	Specifies the transport protocol to be used for remote debug. The valid value and default is UDP.

**Note:** The debug server can only be used to debug already loaded processes; therefore, the pid option must always be specified. Because the Debug Monitor is not a multiprocessing system, the process id specified with this option is ignored.

For example:

```
%ladebug size.out -rn eb64 -pid 0
```

This example connects to the server on the node with IP node name `eb64` and asks to debug the process with pid `0`. The local object file is called `size.out`.

## 3.6 Building the Executable File

To build the executable file for remote debugging, follow these steps:

1. Compile your source files using the `-g` option. This preserves the symbolic information in the source files.
2. Link the source files with the `-N` and `-Tx` options; where `x` is the load address for the executable on the motherboard.
3. Use the CSTRIP utility to strip the coff header from the executable file. Keep the unstripped executable file.

## Starting a Ladebug Session

### 3.7 Starting a Ladebug Session

The Debug Monitor **ladebug** command configures the motherboard as a remote debugger target. Communication is performed through the Ethernet connection.

To debug a program running on a motherboard using Ladebug running on a remote host, follow these steps:

1. Set up the host DIGITAL UNIX machine as described in Chapter 2.
2. Start the motherboard.
3. Load the program into memory on the motherboard.
4. Set a breakpoint in the program.
5. Execute the program. The program will stop at the breakpoint and print the instruction line at that location.
6. Issue the **ladebug** command. This causes the motherboard to wait for a connection from Ladebug.
7. From the host system, enter the command to start Ladebug and cause it to connect to the motherboard.

The following example shows how to set up a sample session:

```
EB64> netload size
Ethernet Base Address: 360, DMA Mask: 1 = DRQ5
Init Block Address 100000
Init Done.
Ethernet BA-98-76-54-32-01
Attempting BOOTP...success.
    my IP address: 16.123.45.67
    server IP address: 16.123.45.69
    gateway IP address: 16.123.45.69
Loading from /users/eval/boot/size ...
####
EB64> stop 200000
EB64> go
Executing at 0x200000...

00200000: 23DEFFF0          lda    sp, -16(sp)
EB64> ladebug
Ethernet Base Address: 360, DMA Mask: 1 = DRQ5
Init Block Address 100000
Init Done.
Client connected : client is FFFFFFFFA0107F10
```

## Starting a Ladebug Session

The following command, entered from the host system, starts Ladebug and causes it to connect to the EB64:

```
% ladebug size.out -rn eb64 -pid 0
Welcome to the Ladebug Debugger Version 1.3.1
-----
object file name: size.out
machine name: eb64
process id: 0
Reading symbolic information ...done
Connected to remote debugger
(ladebug)
```

The `(ladebug)` in the previous example is the Ladebug prompt. You are now ready to debug a process that is running on the EB64. To end this session and return to the Debug Monitor command prompt, use the Ladebug `quit` command to disconnect from the server.

Refer to the Ladebug documentation for more information about how to run Ladebug.





---

## User Commands

### 4.1 Overview

This chapter describes how to use the Alpha Microprocessors Motherboard Debug Monitor commands.

The Debug Monitor supports advanced command line editing, including cursor key movements and an Emacs-like editing interface. In addition, a history buffer has been added to facilitate repetition of commands.

<i>(Sheet 1 of 2)</i>	
<b>Keys</b>	<b>Description</b>
. (period)	Repeats the last command entered.
↑(up arrow) Ctrl/P <sup>1</sup>	Scrolls up (older entries) the history buffer.
↓ (down arrow) Ctrl/N	Scrolls down (newer entries) the history buffer.
← (left arrow) Ctrl/B	Moves cursor one character to the left.
→ (right arrow) Ctrl/F	Moves cursor one character to the right.
Backspace Delete Ctrl/H	Deletes the character preceding the cursor.
Ctrl/D	Deletes character at cursor position.
Ctrl/K	Deletes text from cursor to end of line.
Ctrl/R	Refreshes the current line.

# Using the Commands

<i>(Sheet 2 of 2)</i>	
<b>Keys</b>	<b>Description</b>
Ctrl/U	Erases the current line of command text.
End <sup>2</sup> Ctrl/E	Moves to the end of the line.
Esc/B	Moves cursor to the previous word.
Esc/Backspace Esc/DELETE	Deletes previous word.
Esc/D	Deletes the next word.
Esc/F	Moves cursor to the next word.
Home <sup>2</sup> Ctrl/A <sup>1</sup>	Moves to the beginning of the line.
Insert	Toggles between insert and overwrite mode.
Return Ctrl/J Ctrl/M	Enters current command.

<sup>1</sup>If you connected to the motherboard through the DIGITAL UNIX `tip` command, you must press Ctrl/P twice to obtain the normal effect of Ctrl/P.

<sup>2</sup>This key requires that the keyboard be connected directly to the motherboard.

## 4.2 Using the Commands

This section describes the Debug Monitor command categories.

- Download and execution commands

The motherboard software basic load command expects to receive Motorola S-records that are stored in the appropriate memory location. The Ethernet port provides improved download performance by using the Internet BOOTP protocol (a UDP-based protocol). This feature allows the motherboard system to determine its Internet address, the address of a boot server, and the name of a file to boot. The Debug Monitor also supports loading files from a floppy drive or the secondary ROM socket.

The execution commands can be used to transfer control to a program in memory. These commands begin executing a program in memory at the specified address, or automatically with a download command.

- Examine and modify memory commands

These commands are used to examine and change memory in various formats beginning at a specified address and ending at a specified address. Quadwords (64 bits), longwords (32 bits), halfwords (16 bits), and bytes (8 bits) are all supported by these commands.

- PCI commands

These commands are used to access PCI configuration space.

- Utility commands

These commands are used to display and modify the date and time, display the version of the Debug Monitor, and obtain information about commands implemented in the current version.

- Debug commands

These commands are used to debug software. Debug commands display internal CPU registers and provide debug capabilities, including breakpoints and single stepping.

- Miscellaneous commands

These commands are used to read and write the system register, perform an interrupt acknowledge cycle, call a subroutine, and connect to serial communication ports.

- Ethernet commands

These commands are used to set up and verify status of the Ethernet port.

- Diagnostic commands

These commands are used to verify that the motherboard is working properly.

## User Commands Quick Reference

### 4.3 User Commands Quick Reference

Table 4–1 contains a summary of all Debug Monitor commands. The commands are grouped by category and function.

**Table 4–1 Command Summary Table**

*(Sheet 1 of 7)*

Command	Parameters	Description
<b>Download and Execution Commands</b>		
load	address	Downloads a file through the active serial port using the XMODEM protocol.
boot	address	Downloads a file through the active serial port using the XMODEM protocol and begins execution.
netload	file, address	Downloads the specified file through the Ethernet port at the current boot address or specified address.
netboot	file, address	Downloads the specified file through the Ethernet port and begins execution.
fld	drive_pathname	Changes the current working directory to the specified drive or path.
flcopy	source_file, destination_file	Copies the specified file to another location.
fldir	drive_pathname	Displays a list of files in the current or specified directory.
flload	file, address	Downloads the specified diskette file.
flboot	file, address	Downloads the specified diskette file and begins execution.
flread	first_sector, bytes, dest_address, iterations, drive	Reads logical sectors from a diskette.
flwrite	first_sector, image_size, source_address, iterations, drive	Writes data by logical sectors to a diskette.
flsave	file_name, start_address, file_size	Saves the specified memory range to the specified file.
romload	type, address	Loads the specified image from ROM to the specified address.

## User Commands Quick Reference

**Table 4–1 Command Summary Table**

(Sheet 2 of 7)

Command	Parameters	Description
romboot	type, address	Loads the specified image from ROM and begins execution.
romlist	none	Lists the ROM image headers contained in ROM.
romverify	type, address	Compares an image in memory to an image in ROM.
bootadr	address	Sets default boot address.
bootopt	type	Selects the operating system and firmware type to be used on the next power-up.
go	start_address	Starts execution at the specified address.
jtopal	start_address	Starts execution at the specified address in PALmode.
init	none	Reinitializes the Debug Monitor.
<b>Examine and Modify Memory Commands</b>		
eml	address, iterations, silent	Displays longword data at the specified memory address.
emq	address, iterations, silent	Displays quadword data at the specified memory address.
dml	address, data, iterations	Deposits the specified longword data in the specified memory address.
dmq	address, data, iterations	Deposits the specified quadword data in the specified memory address.
pq	start_address, end_address, iterations, silent	Prints memory in quadword (64-bit) format.
pl	start_address, end_address, iterations, silent	Prints memory in longword (32-bit) format.
pw	start_address, end_address, iterations, silent	Prints memory in word (16-bit) format.
pb	start_address, end_address, iterations, silent	Prints memory in byte (8-bit) format.
cq	address	Edits memory quadwords (64-bit).

## User Commands Quick Reference

Table 4–1 Command Summary Table

(Sheet 3 of 7)

Command	Parameters	Description
cl	address	Edits memory longwords (32-bit).
cw	address	Edits memory words (16-bit).
cb	address	Edits memory bytes (8-bit).
fill	start_address, end_address, fill_value	Fills the specified memory block with the specified 32-bit pattern.
copy	start_address, end_address, destination	Copies a memory range to the specified address.
compare	start_address, end_address, compare_address	Compares a memory range to a specified address.
dis	start_address, end_address	Displays memory as CPU instructions.
sum	start_address, end_address	Prints a checksum of a memory range.
rl	register, iterations, silent	Reads a longword from a register port in I/O address space.
rw	register, iterations, silent	Reads a word from a register port in I/O address space.
rb	register, iterations, silent	Reads a byte from a register port in I/O address space.
wl	register, data, iterations	Writes a longword to a register port in I/O address space.
ww	register, data, iterations	Writes a word to a register port in I/O address space.
wb	register, data, iterations	Writes a byte to a register port in I/O address space.
mrl	address, iterations, silent	Reads a longword from memory in I/O address space.
mrw	address, iterations, silent	Reads a word from memory in I/O address space.

**Table 4–1 Command Summary Table**

(Sheet 4 of 7)

Command	Parameters	Description
mrbl	address, iterations, silent	Reads a byte from memory in I/O address space.
mwll	address, data, iterations	Writes a longword to memory I/O address space.
mwll	address, data, iterations	Writes a word to memory I/O address space.
mwbl	address, data, iterations	Writes a byte to memory I/O address space.
sq	start_address, end_address, string, inverse	Searches the specified memory range by quadwords for the specified pattern.
sl	start_address, end_address, string, inverse	Searches the specified memory range by longwords for the specified pattern.
sw	start_address, end_address, string, inverse	Searches the specified memory range by words for the specified pattern.
sb	start_address, end_address, string, inverse	Searches the specified memory range by bytes for the specified pattern.
<b>PCI Commands</b>		
pcishow	id, bus, function	Displays the contents of each PCI slot and current PCI to system address space mapping.
prll	pci_address, id, bus, function	Reads a longword from the specified address in PCI configuration space.
prwl	pci_address, id, bus, function	Reads a word from the specified address in PCI configuration space.
prbl	pci_address, id, bus, function	Reads a byte from the specified address in PCI configuration space.
prll	pci_address, id, data, bus, function	Writes a longword to a specified address in PCI configuration space.
prwl	pci_address, id, data, bus, function	Writes a word to a specified address in PCI configuration space.

## User Commands Quick Reference

**Table 4–1 Command Summary Table**

(Sheet 5 of 7)

Command	Parameters	Description
pwb	pci_address, id, data, bus, function	Writes a byte to a specified address in PCI configuration space.
<b>Utility Commands</b>		
bcon	none	Enables the backup cache.
bcoff	none	Disables the backup cache.
date	yymmddhhmmss	Modifies or displays the date and time.
flash	source_address, destination_offset, bytes_to_write	Programs data into flash memory.
flasherase	starting_offset, bytes_to_erase	Erases data from flash memory.
fwupdate	none	Loads and runs the firmware update utility.
help	command_name	Displays a list of commands or displays parameter fields and syntax if a command is specified.
apropos	keyword	Displays help text containing the specified keyword.
ident	start_address, end_address	Displays RCS ID strings found in the specified memory range.
sysshow	none	Displays SROM parameters.
version	none	Displays the Debug Monitor firmware version information.
swpipl	ipl	Sets or displays the current interrupt priority level, IPL of the CPU.
mces	mces_data	Sets or displays the machine check error summary register.
wrfen	value	Enables/disables floating point.
<b>Debug Commands</b>		
preg	address	Displays CPU general-purpose registers.
pfreg	address	Displays CPU floating-point registers.
creg	register_number, value	Modifies CPU general-purpose registers.
cfreg	register_number, value	Modifies CPU floating-point registers.



## User Commands Quick Reference

**Table 4–1 Command Summary Table**

(Sheet 6 of 7)

Command	Parameters	Description
stop	address	Sets a breakpoint at the specified address.
bpstat	none	Displays the current breakpoint status.
step	none	Executes a machine instruction by stepping into the first instruction of the function being called.
next	none	Executes a machine instruction without stepping into subroutines.
cont	none	Continues execution from a breakpoint.
delete	address	Removes breakpoint from the specified address.
ladebug	none	Starts a Ladebug server for a remote debug session.
<b>Miscellaneous Commands</b>		
rsys	none	Reads the EB64 system control register.
wsys	data	Writes the EB64 system control register.
rabox	none	Reads the CPU ABOX_CTL register.
wabox	data	Writes to the CPU ABOX_CTL register.
rbiu	none	Reads the CPU BIU_CTL register.
wbiu	data	Writes to the CPU BIU_CTL register.
riccsr	none	Reads the CPU ICCSR register.
wiccsr	data	Writes to the CPU ICCSR register.
rbcfg	none	Reads the backup cache configuration register.
wbcfg	bcfg_data, bctl_data	Writes to the backup cache configuration register.
rbctl	none	Reads the backup cache control register.
wbctl	bctl_data, bcfg_data	Writes to the backup cache control register.
iack	none	Performs an interrupt acknowledge cycle.
rmode	mode	Sets the <b>dis</b> command register display mode.
setty	port	Specifies the port used for Debug Monitor interaction.
setbaud	port, baud_rate	Sets the communication port baud rate. The default is 9600.
tip	port	Connects to a specified serial communication port.

## User Commands

Table 4–1 Command Summary Table

(Sheet 7 of 7)

Command	Parameters	Description
<b>Ethernet Commands</b>		
edevic	device_number	Selects a registered Ethernet device.
eshow	none	Displays all registered Ethernet devices.
ereg	none	Displays the Ethernet controller registers.
estat	none	Displays Ethernet statistics.
einit	none	Initializes Ethernet controller and displays the Ethernet hardware address.
estop	none	Stops the Ethernet controller.
ebuff	address	Sets the base address for Ethernet DMA buffers.
edmp	status	Sets or clears display of packets received or transmitted.
eprom	status	Sets or clears flag for receiving all packets (promiscuous mode).
arpshow	none	Displays all known address resolution protocol (ARP) entries.
<b>Diagnostic Commands</b>		
beep	duration, frequency	Causes speaker to beep for the specified duration and frequency.
mcheck	state	Controls the reporting of hardware error conditions (machine checks).
memtest	iterations, start_address, end_address, increment, mcheck, stop_drivers	Tests memory range. Uses longword accesses to memory.

### 4.4 User Commands

The following section contains complete descriptions and examples of the Debug Monitor commands. The commands are listed in alphabetical order.

## apropos

The **apropos** command displays help descriptions for the specified keyword.

### Format

**apropos** keyword

### Parameters

#### **keyword**

Specifies the string to match in the **help** command text.

### Description

The **apropos** command is an additional form of help. This command searches the help file and displays all matches for the specified keyword.

### Example

```
EB66> apropos load
load:
  Downloads S records through a serial port
  syntax: load
  arguments:

boot:
  Downloads S records through a serial port and begins execution
  syntax: boot
  arguments:

netload:
  Downloads file via the Ethernet port to address. Address
  defaults to bootadr
  syntax: netload file address
  arguments: <opt str> <opt hex>

netboot:
  Downloads file through the Ethernet port and begins execution
  syntax: netboot file address
  arguments: <opt str> <opt hex>

      Hit any key to continue. Control-C to quit...
```

## User Commands

### arpshow

### arpshow

The **arpshow** command displays all known address resolution protocol (ARP) entries.

### Format

**arpshow**

### Parameters

None.

### Description

The **arpshow** command displays an IP routing table entry. If there are no ARP entries, nothing is shown for that device. The Ethernet device number displayed matches the number that is displayed when the **eshow** and **edev** commands are entered.

### Example

```
EB64> arpshow
```

```
Arp Table Contents (at 0x00074570):
```

```
    Ethernet Device 0  
    IP Address: 16.123.45.67  
    MAC Address: BA-98-76-54-32-10
```

## bcoff

The **bcoff** command disables the backup cache.

## Format

**bcoff**

## Parameters

None.

## Description

The **bcoff** command disables the external (backup) cache. Use of this command assumes that the cache has already been initialized (usually by the SROM). If the cache is initialized but already disabled, this command has no effect on the state of the cache.

## Example

```
EB66+ bcoff  
...CAR = 67B0D8E840031294
```

```
EB164> bcoff  
Old BC_CTL = 0x00028051 & BC_CFG = 0x01E22772  
New BC_CTL = 0x00028050 & BC_CFG = 0x01E25880  
CIA_CACK_EN = 0x0 & CIA_MCR = 0x0001FE01
```

## User Commands

### bcon

### bcon

The **bcon** command enables the backup cache.

### Format

**bcon**

### Parameters

None.

### Description

The **bcon** command enables the external (backup) cache when it has been disabled using the **bcoff** command. If the cache has never been initialized (usually by the SROM), the **bcon** cannot be expected to be capable of enabling it. If the cache is already enabled, this command has no effect on the state of the cache.

### Example

```
EB66+ bcon
...CAR = EFB0D8E940031295

EB164> bcon
Old BC_CTL = 0x00028050 & BC_CFG = 0x01E25880
New BC_CTL = 0x00028051 & BC_CFG = 0x01E22772
    CIA_CACK_EN = 0x8 & CIA_MCR = 0x0001FE21
```

## beep

The **beep** command tests the speaker.

### Format

**beep** duration frequency

### Parameters

#### duration

Specifies the duration of the beep in milliseconds.

#### frequency

Specifies the frequency in hertz.

### Description

The **beep** command causes the speaker to beep for the specified duration and frequency.

### Example

```
EB64> beep 1000 4000
```

## User Commands

### boot

### boot

The **boot** command downloads a file through the active serial port using the XMODEM protocol and begins execution.

### Format

**boot** [address]

### Parameters

#### address

Specifies the address at which to download the file. The default is the boot address.

### Description

The **boot** command uses the XMODEM protocol to download a file through the active serial port. The program is loaded to the supplied address or to the boot address if an address is not specified. The program is then automatically executed.

### Example

In this example, a DIGITAL UNIX host system is connected to the motherboard on device `/dev/tty01`. The `sx` command sends a file using XMODEM.

```
% echo boot 300000 > /dev/tty01
% sx -kt 10 /users/eval1/demo2/size </dev/tty01 >/dev/tty01
Sector nnn
% tip /dev/tty01
AlphaPC164>
```



## bootadr

The **bootadr** command allows you to display or modify the default boot address.

### Format

**bootadr** [address]

### Parameters

#### address

Specifies the starting address at which a program is loaded. Programs loaded with the **netboot** command automatically begin program execution at this address. The default address is  $300000_{16}$ .

### Description

The boot address is the address at which your programs load and begin execution. The **bootadr** command sets the default address for the load commands to begin execution or to download your program into memory. If the **bootadr** command is specified without an address, the command displays the current default boot address. If you set the boot address value, the value is stored in battery-backed RAM.

### Example

This example sets the starting address to  $20000_{16}$ . The next file that is loaded begins execution from this address.

```
EB64> bootadr 20000
```

## User Commands

### bootopt

### bootopt

The **bootopt** command selects the operating system and firmware type to be used on the next power-up.

### Format

**bootopt** [type]

### Parameters

#### type

Specifies the operating system type. If the specified image is not found at power-up, the first image is booted. If there are no ROM headers, the whole ROM will be loaded at address 0.

### Description

The **bootopt** command selects the operating system and associated firmware type that will be used the next time you power up your motherboard. If no type is specified, a list of predefined types is displayed along with the current selection. Use the **romlist** command to display the images contained in the ROM. You can specify the type as a number or a name.

Type_number	Type_name	Description
0	DBM	Alpha Motherboard Debug Monitor
1	NT	Windows NT
2	VMS	OpenVMS
3	UNIX	DIGITAL UNIX
7	LINUX	Linux, MILO
8	VXWORKS	VxWorks
10	SROM	Serial ROM

The **bootopt** command can also be used to select a ROM image based on its position in the ROM. Specifying the type as #0 selects the whole ROM. Specifying the type as #1 selects the first image; #2 selects the second image, and so on. The **bootopt** command is not supported for the EB64+, EB66, or EB64.

## Example

```
AlphaPC 64> bootopt
Predefined bootoptions are...
  "0" "Alpha Evaluation Board Debug Monitor" "DBM"
  "1" "The Windows NT Operating System" "NT"
  "2" "OpenVMS" "VMS"
  "3" "DIGITAL UNIX, formerly DEC OSF/1" "UNIX"
  "7" "Linux" "Milo"
  "8" "VxWorks. Real-Time Operating System" "VxWorks"
  "10" "Serial ROM (SROM)" "SROM"
O/S type selected: "OpenVMS"
...Firmware type: "Alpha SRM Console"
AlphaPC 64> bootopt 0
O/S type selected: "Alpha Evaluation Board Debug Monitor"
...Firmware type: "Alpha Evaluation Board Debug Monitor"
AlphaPC 64> bootopt nt
O/S type selected: "The Windows NT Operating System"
...Firmware type: "Windows NT Firmware"
AlphaPC 64> bootopt #1
Firmware image 1 selected.
...Firmware type: "Unknown"
AlphaPC 64> bootopt unix
O/S type selected: "DIGITAL UNIX, formerly DEC OSF/1"
...Firmware type: "Alpha SRM Console"
AlphaPC 64> bootopt #0
Load and boot entire ROM at address zero.
...Firmware type: "Unknown"
AlphaPC 64> bootopt
Predefined bootoptions are...
  "0" "Alpha Evaluation Board Debug Monitor" "DBM"
  "1" "The Windows NT Operating System" "NT"
  "2" "OpenVMS" "VMS"
  "3" "DIGITAL UNIX, formerly DEC OSF/1" "UNIX"
  "7" "Linux" "Milo"
  "8" "VxWorks. Real-Time Operating System" "VxWorks"
  "10" "Serial ROM (SROM)" "SROM"
Load and boot entire ROM at address zero.
...Firmware type: "Unknown"
```

## User Commands

### bpstat

### bpstat

The **bpstat** command displays the current breakpoint status.

### Format

**bpstat**

### Parameters

None.

### Description

The **bpstat** command lists the breakpoints set with the **stop** command. The disassembled instructions for that location are also displayed.

### Example

```
EB64> stop 200000
EB64> stop 200FC0
EB64> bpstat
{break} at 00200000: 23DEFFF0      lda    sp, -16(sp)
{break} at 00200FC0: 27BB0001      ldah   r29, 1(r27)
```

## cb

The **cb** command allows you to edit memory bytes (8-bit).

### Format

**cb** [address]

### Parameters

#### address

Specifies the address of the memory byte you want to change.

### Description

The **cb** command allows you to modify the contents of a specified memory address. If no address is specified, then the next byte is selected. The Debug Monitor displays the address followed by the current data and a colon (:). For example:

```
00200090: 1D :
```

To modify the contents of this memory location, type the new data after the colon and press the Return key. To end the editing of memory locations, type any nonalphanumeric character except a period (.). The nonalphanumeric character can be typed after the modified byte (on the same line). To leave the current location unchanged, press the Return key on an empty line.

### Example

In this example, the bytes at  $300000_{16}$  and  $300003_{16}$  have been modified, leaving the ones at  $300001_{16}$  and  $300002_{16}$  unchanged.

```
EB164> pb 300000 300008
00300000: 1f 04 ff 47 1f 04 ff 47 45 00 60 c3 00 00 00 00 ...G...GE.`.....
EB164> cb 300000
00300000: 1f: aa
00300001: 04:
00300002: ff:
00300003: 47: dd
00300004: 1f: ;
EB164> pb 300000 300008
00300000: aa 04 ff dd 1f 04 ff 47 45 00 60 c3 00 00 00 00 .....GE.`.....
```

## User Commands

### cfreg

#### cfreg

The **cfreg** command modifies the saved CPU floating-point register state.

#### Format

**cfreg** register\_number value

#### Parameters

##### **register\_number**

Identifies the register.

##### **value**

Specifies the new value of the register in hexadecimal numbers.

#### Description

The **cfreg** command modifies the saved CPU floating-point register state to contain the specified value.

The program register contents are stored in memory to the saved-state area when a breakpoint is encountered. Modifications to a register using the **cfreg** command are applied to that register when execution of the program is resumed using the **step** or the **cont** command.

## Example

```
EB64> pfreg
Floating Point Registers
register file @: 0000C840
f00: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f04: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f08: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f12: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f16: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f20: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f24: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f28: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
PC: 000000000000000D PS: 000000000000000D
EB64> cfreg 12 abababab
EB64> cfreg 14 fefefefefe
EB64> pfreg
Floating Point Registers
register file @: 0000C840
f00: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f04: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f08: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f12: 000000ABABABAB 0000000000000000 000000FEFEFEFEFE 0000000000000000
f16: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f20: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f24: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f28: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
PC: 000000000000000D PS: 000000000000000D
```

## User Commands

**cl**

**cl**

The **cl** command allows you to edit memory longwords (32-bit).

### Format

**cl** [address]

### Parameters

**address**

Specifies the address of the memory longword you want to change.

### Description

The **cl** command allows you to modify the contents of a specified memory address. If no address is specified, then the next longword is selected. The Debug Monitor displays the address followed by the current data and a colon (:). For example:

```
00200090: E7E0101D :
```

To modify the contents of this memory location, type the new data after the colon and press the Return key. To end the editing of memory locations, type any nonalphanumeric character except a period (.). The nonalphanumeric character can be typed after the modified byte (on the same line). To leave the current location unchanged, press the Return key on an empty line.

### Example

In this example, the memory data at address 0 has been modified from 91E01122 to E7E01021.

```
EB64> cl 0
00000000: 91E01122: e7e01021
EB64> p 0 0
00000000: E7E01021 00000000 00000000 00000000 !.....
```



## compare

The **compare** command compares a memory range to a specified address.

### Format

**compare** start\_address end\_address compare\_address

### Parameters

#### start\_address

Specifies the memory address at which to start the comparison.

#### end\_address

Specifies the last address that will be compared.

#### compare\_address

Specifies the address to be compared to the memory range.

### Description

The **compare** command compares each longword (32 bits) within a specified range in memory to another specified location. It then prints the data that differ.

### Example

```
EB66+ copy 3fff80000 3fffd0000 400000
EB66+ fill 400200 400220
EB66+ fill 400400 400440 ffffffff
EB66+ compare 3fff80000 3fffd0000 400000
3FFF80200: 64 86 00 E7 64 00 80 FF 00400200: 00 00 00 00 00 00 00 00
3FFF80208: 7B 06 78 C3 44 A0 10 C0 00400208: 00 00 00 00 00 00 00 00
3FFF80210: F4 9B 10 E0 C3 80 00 80 00400210: 00 00 00 00 00 00 00 00
3FFF80218: 00 CC 00 64 83 00 84 74 00400218: 00 00 00 00 00 00 00 00
3FFF80400: E2 39 37 05 49 99 76 26 00400400: FF FF FF FF FF FF FF FF
3FFF80408: 4B 96 16 C4 4A 36 B7 C1 00400408: FF FF FF FF FF FF FF FF
3FFF80410: 4A 16 04 36 43 00 90 D6 00400410: FF FF FF FF FF FF FF FF
3FFF80418: 6E 0D 00 C0 E2 20 00 08 00400418: FF FF FF FF FF FF FF FF
3FFF80420: 75 40 00 D6 76 42 00 D6 00400420: FF FF FF FF FF FF FF FF
3FFF80428: 76 97 00 08 65 88 00 D6 00400428: FF FF FF FF FF FF FF FF
3FFF80430: 66 95 00 39 67 00 80 FF 00400430: FF FF FF FF FF FF FF FF
3FFF80438: 79 7B 44 00 39 67 99 36 00400438: FF FF FF FF FF FF FF FF
3FFFD0000: FF FF FF FF FF FF FF FF 00450000: 2D 00 00 00 00 00 00 00
```

## User Commands

### cont

### cont

The **cont** command continues execution from a breakpoint.

### Format

**cont**

### Parameters

None.

### Description

The **cont** command continues from a breakpoint. The program continues until another breakpoint or the end of the program is reached.

### Example

```
EB64> stop 100000
EB64> go
Executing at 0x100000...
00100000: C1000003          br    r8, 100010
EB64> step
00100010: 2F880007          ldq_u r28, 7(r8)
EB64> step
00100014: A49E0000          ldq   r4, 0(sp)
EB64> cont
This simple program prints the sizes of
various data types in bytes.
char    = 1
short   = 2
int     = 4
long    = 8
float   = 4
double  = 8
```

## copy

The **copy** command copies the specified memory range to the new specified address.

### Format

```
copy start_address end_address destination
```

### Parameters

#### **start\_address**

Specifies the starting address for this copy.

#### **end\_address**

Specifies the last address to be included in this copy.

#### **destination**

Specifies the new starting address for the memory range.

### Description

The **copy** command copies the data from the specified block of memory to a new location in memory. The original location is unchanged.

## User Commands

### copy

### Example

This example displays the original location and the destination before and after the copy command.

```
EB64> p1 8000000
08000000: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000010: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000020: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000030: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000040: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000050: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000060: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000070: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
EB64> p1 9000150
09000150: 00000000 00000000 00000000 00000000 .....
09000160: 00000000 00000000 00000000 00000000 .....
09000170: 00000000 00000000 00000000 00000000 .....
09000190: 00000000 00000000 00000000 00000000 .....
090001A0: 00000000 00000000 00000000 00000000 .....
090001B0: 00000000 00000000 00000000 00000000 .....
090001C0: 00000000 00000000 00000000 00000000 .....
EB64> copy 8000000 8000080 9000150
EB64> p1 9000150
09000150: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
09000160: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
09000180: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
09000190: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
090001A0: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
090001B0: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
090001C0: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
EB64> p1 8000000
08000000: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000010: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000020: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000030: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000040: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000050: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000060: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000070: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
```

## **cq**

The **cq** command allows you to edit memory quadwords (64-bit).

### **Format**

**cq** [address]

### **Parameters**

#### **address**

Specifies the address of the memory quadword you want to change.

### **Description**

The **cq** command allows you to modify the contents of the specified memory address. If no address is specified, then the next quadword is selected. The Debug Monitor displays the address followed by the current data and a colon (:). For example:

```
00200090: 00000000E7E0101D :
```

To modify the contents of this memory location, type the new data after the colon and press the Return key. To end the editing of memory locations, type any nonalphanumeric character except a period (.). The nonalphanumeric character can be typed after the modified byte (on the same line). To leave the current location unchanged, press the Return key on an empty line.

## User Commands

cq

### Example

This example modifies only quadword 200020<sub>16</sub>.

```
EB64> cq 200020
00200020: 0000000004000000: 0000000011111111
00200028: 0000000000000000:
00200030: 3402010400120106:
00200038: 0402010004020100:
00200040: FBFDFFFFFFFDFFF ;
EB64> pq 200000
00200000: FA7D7299CE7F3299 DA65FA99DA7D32D9 .2...r}..2}...e.
00200010: FFFFFFFFBFBFFBFFDB FFFFFFFF.....
00200020: 0000000011111111 0000000000000000 .....
00200030: 3402010400120106 0402010004020100 .....4.....
00200040: FBFDFFFFFFFDFFF FBFDFFFFFFBFDFFF .....
00200050: CFE7FF99CB6FF799 EEE7FBFBFFFFFFF ..o.....
00200060: 0000000004020000 0000000000000000 .....
00200070: 1402010620100106 050A050004020100 ... .....
```

## creg

The **creg** command modifies the saved CPU general-purpose register state.

### Format

**creg** register\_number value

### Parameters

#### **register\_number**

Identifies the register.

#### **value**

Specifies the new value of the register in hexadecimal numbers.

### Description

The **creg** command modifies the saved CPU general-purpose register state to contain the specified value.

The program register contents are stored in memory to the saved-state area when a breakpoint is encountered. Modifications to a register using the **creg** command are applied to that register when execution of the program is resumed using the **step** or **cont** command.

## User Commands

### creg

### Example

```
EB64> preg
General Purpose Registers
register file @: 0000C040
r00: 0000000000000020 0000000000000005 000000000000C000 000000000000000D
r04: 000000000000003F8 0000000000000000 0000000000000000 000000000000000D
r08: FFFFFFFC000005F470 0000000000027340 0444306453605341 0A110C485F6EA26E
r12: 208090EA6024C19C 882C08AA92065B2D 4100610AE100244F 9E2891ACA8A9D984
r16: 000000000100000 000000000000000D 0000000000000006 0000000000000030
r20: 0000000E20026335 5619A46B2B1A5125 0000000000000000 000000000000000D
r24: 0000000000000003 0000000000000000 FFFFFFFC0000042C3C 000000000100000
r28: FFFFFFFC02C0000000 FFFFFFFC000006C1E0 0000000000FFDF40 0000000000000003
PC: 000000000000000D PS: 000000000000000D
EB64> creg 04 555
EB64> preg
General Purpose Registers
register file @: 0000C040
r00: 0000000000000020 0000000000000005 000000000000C000 000000000000000D
r04: 00000000000000555 0000000000000000 0000000000000000 000000000000000D
r08: FFFFFFFC000005F470 0000000000027340 0444306453605341 0A110C485F6EA26E
r12: 208090EA6024C19C 882C08AA92065B2D 4100610AE100244F 9E2891ACA8A9D984
r16: 000000000100000 000000000000000D 0000000000000006 0000000000000030
r20: 0000000E20026335 5619A46B2B1A5125 0000000000000000 000000000000000D
r24: 0000000000000003 0000000000000000 FFFFFFFC0000042C3C 000000000100000
r28: FFFFFFFC02C0000000 FFFFFFFC000006C1E0 0000000000FFDF40 0000000000000003
PC: 000000000000000D PS: 000000000000000D
```



**cw**

The **cw** command allows you to edit memory words (16-bit).

**Format**

**cw** [address]

**Parameters****address**

Specifies the address of the memory word you want to change.

**Description**

The **cw** command allows you to modify the contents of the specified memory address. If no address is specified, then the next word is selected. The Debug Monitor displays the address followed by the current data and a colon (:). For example:

```
00200090: 101D :
```

To modify the contents of this memory location, type the new data after the colon and press the Return key. To end the editing of memory locations, type any nonalphanumeric character except a period (.). The nonalphanumeric character can be typed after the modified byte (on the same line). To leave the current location unchanged, press the Return key on an empty line.

## User Commands

**cw**

### Example

This example modifies words 200094<sub>16</sub> through 200098<sub>16</sub>.

```
EB64> pw 200090
00200090: 3BB9 CA6D FFB9 CFE7 3FBF FFFF 33F9 CE67.;m.....?...3g.
002000A0: 0000 0400 0000 0000 0000 0000 0000 0000.....
002000B0: 8166 309A 4166 3402 8960 0402 8D46 359Af..0fA.4`...F..5
002000C0: FFFF FFFD FFFF FBFD FFFF FBFD FFFF FBFD.....
002000D0: 3399 DA65 BB99 CFF7 37BF FFFF 33D9 CE67.3e.....7...3g.
002000E0: 0000 0000 0000 0000 0000 0000 0000 0000.....
002000F0: 8142 2012 0166 3402 8140 0402 4504 049A B..f..4@....E..
00200100: FFFF FFFD FFFF FBFD FFFF FBFD FFFF FBFD.....
EB64> cw 200090
00200090: 3BB9:
00200092: CA6D:
00200094: FFB9: ffff
00200096: CFE7: 0000
00200098: 3FBF: 0101
0020009A: FFFF: ;
EB64> pw 200090 20009A
00200090: 3BB9 CA6D FFFF 0000 0101 FFFF 33F9 CE67.;m.....3g.
```

## date

The **date** command displays or modifies the date and time.

### Format

**date** [yymmddhhmmss]

### Parameters

**yymmddhhmmss**

To modify the date, supply the year, month, day, hour, minute, and second.

### Description

If the **date** command is specified alone, the month, day, time, and year is displayed.

If you supply a parameter, the date is modified.

### Example

This example displays the current date and time setting.

```
EB64> date
Jun  1 12:58:19 1992
```

These examples show how to modify the date and time setting.

```
EB64> date 930211000000
EB64> date
Feb 11 00:00:04 1993
EB64> date 930211135700
EB64> date
Feb 11 13:57:02 1993
```

## User Commands

### delete

#### delete

The **delete** command removes a breakpoint from the specified address.

#### Format

**delete** address

#### Parameters

##### address

Specifies the address from which to delete the breakpoint.

#### Description

The **delete** command removes a breakpoint from the specified address. You can use an asterisk (\*) to remove all breakpoints.

#### Example

```
EB64> delete 00200050
```

## dis

The **dis** command displays memory as CPU instructions.

### Format

```
dis [start_address [end_address]]
```

### Parameters

#### start\_address

Specifies the address at which to start disassembling instructions. If the `start_address` is *not* specified, the address of the last **load** command, the last breakpoint, or the last **dis** command is used.

#### end\_address

Specifies the address at which to end disassembling instructions. The default is the `start_address` plus 32 bytes (8 instructions).

### Description

The **dis** command disassembles instructions starting with the specified address. You can specify an address range of instructions to be disassembled. If no parameters are specified, then the command starts with the current address and disassembles the next eight instructions. If a file is downloaded to memory, then the default starting address for the **dis** command is the first memory location in the downloaded file. If a breakpoint is encountered, then the default starting address is the breakpoint address.

The **rmode** command is used to select whether the hardware or software register names are displayed when instructions are disassembled. The hardware register names are shown by default. The **rmode** setting is stored in nonvolatile RAM.

## User Commands

### dis

### Example

```
EB64> dis 243a0
000243A0: 43020122      subl    r24, r2, r2
000243A4: 48441722      sll    r2, 0x20, r2
000243A8: 74420050      mt     r2, cc
000243AC: 64630082      mf     r3, pt2
000243B0: 209F07E1      lda   r4, 2017(zero)
000243B4: 48855724      sll    r4, 0x2A, r4
000243B8: 44640103      bic   r3, r4, r3
000243BC: 47203019      and   r25, 0x1, r25
EB64> dis
000243C0: 4B037698      srl   r24, 0x1B, r24
000243C4: 4703F118      bic   r24, 0x1F, r24
000243C8: 47190418      bis   r24, r25, r24
000243CC: 4B055738      sll   r24, 0x2A, r24
000243D0: 44780403      bis   r3, r24, r3
000243D4: 746300A2      mt    r3, A2
000243D8: 77FF0055      mt    zero, flushIc
000243DC: 77FF0000      mt    zero, 0
EB64>
```

## dml

The **dml** command deposits the specified longword data in the specified memory location.

### Format

**dml** address data [iterations]

### Parameters

#### **address**

Specifies the memory address.

#### **data**

Specifies the longword data to be stored.

#### **iterations**

Specifies how many times the command is executed. The default is 1.

### Description

The **dml** command deposits the specified longword data in the specified memory location. A memory barrier (MB) instruction is executed after the store to force the stored data out of the chip.

### Example

```
EB64> dml d0000 FC04FF00
```

## User Commands

### dmq

### dmq

The **dmq** command deposits the specified quadword data in the specified memory location.

### Format

```
dmq address data [iterations]
```

### Parameters

#### **address**

Specifies the memory address.

#### **data**

Specifies the quadword data to be stored.

#### **iterations**

Specifies how many times the command is executed. The default is 1.

### Description

The **dmq** command deposits the specified quadword data in the specified memory location. A memory barrier (MB) instruction is executed after the store to force the stored data out of the chip.

### Example

```
EB64> dmq d0000 00000000FC04FF00
```



## ebuff

The **ebuff** command sets the base address for the Ethernet transmit receive buffers.

### Format

**ebuff** [address]

### Parameters

#### address

Specifies the address for the transmit and receive buffers. The default is  $100000_{16}$ .

### Description

The **ebuff** command sets the address in physical memory where the transmit and receive buffers are located. If specified without an address, this command displays the current location of the buffers in memory.

### Example

```
EB64> ebuff 180000
```

## User Commands

### **edev**

### **edev**

The **edev** command selects the registered Ethernet device that the Debug Monitor will use.

### **Format**

**edev** [device\_number]

### **Parameters**

#### **device\_number**

Specifies the net device number of any registered Ethernet device. If no device number is provided, the current device number is displayed.

### **Description**

The **edev** command sets the Debug Monitor to use one of the registered Ethernet devices. Use the **eshow** command to display all of the registered Ethernet devices.

### **Example**

```
EB64> eshow
```

```
All registered Ethernet devices:
```

Net Device	Type
0	AM79C960
1	WD3003
2	Digital Semiconductor 21040
3*	Digital Semiconductor 21040

```
EB64> edev 1
```

## edmp

The **edmp** command displays packets received or transmitted to the terminal screen.

### Format

**edmp** [status]

### Parameters

#### status

Determines whether packets are displayed. Status can be 1 (on) or 0 (off).

### Description

The **edmp** command sets or clears the display of packets received or transmitted to the screen. If this command is entered with no status, then the current status is displayed.

### Example

```
EB64> edmp
packet dumps are OFF.
EB64> eprom 1
EB64> edmp 1
```

## User Commands

### einit

### einit

The **einit** command initializes the Ethernet controller.

### Format

**einit**

### Parameters

None.

### Description

The **einit** command initializes the Ethernet controller and displays the Ethernet hardware address.

### Example

```
EB64> einit  
Ethernet Base Address: 360, DMA Mask: 1 = DRQ5  
Init Block Address 80000  
Init Done.  
Ethernet BA-98-76-54-32-10
```

## eml

The **eml** command examines and displays a longword of data in memory.

### Format

**eml** address [iterations [silent]]

### Parameters

#### address

Specifies the memory address.

#### iterations

Specifies how many times the command is executed. The default is 1.

#### silent

Specifies whether or not the data is displayed. Setting this parameter to 1 causes the data to be read but not displayed. The default is 0 (data is displayed).

### Description

The **eml** command displays a longword of data from the specified memory location.

### Example

```
EB64> eml d0000  
FC04FF00
```

## User Commands

### emq

### emq

The **emq** command examines and displays a quadword of data in memory.

### Format

**emq** address [iterations [silent]]

### Parameters

#### address

Specifies the memory address.

#### iterations

Specifies how many times the command is executed. The default is 1.

#### silent

Specifies whether or not the data is displayed. Setting this parameter to 1 causes the data to be read but not displayed. The default is 0 (data is displayed).

### Description

The **emq** command displays a quadword of data from the specified memory location.

### Example

```
EB64> emq d0000  
00000000FC04FF00
```

## eprom

The **eprom** command sets or clears a flag for receiving all packets (promiscuous mode).

### Format

**eprom** [status]

### Parameters

#### status

Determines whether packets are displayed. Status can be 1 (on) or 0 (off).

### Description

The **eprom** command sets a flag for receiving packets. If status is set to 1 (on), then promiscuous mode is turned on and packets can be continuously received. If this command is entered with no status, then the current status is displayed. The default status is 0 (off).

### Example

```
EB64> eprom  
Promiscuous Mode is DISABLED.  
EB64> eprom 1
```

## User Commands

### ereg

### ereg

The **ereg** command displays the Ethernet controller registers.

### Format

**ereg**

### Parameters

None.

### Description

The **ereg** command displays the Ethernet controller registers. This command's output is dependent on the Ethernet device selected for the motherboard. For example, the ISA-based AM79C960 controller must be in stop mode (write 0 to register port 372 and write 4 to data port 370) to view most of its registers.



## Example

```
EB64> ww 372 0
EB64> ww 370 4
EB64> ereg
Ethernet Controller Base Address 360, CSR 0...126
0 0004 1 0000 2 0008 3 0000 4 1115 5 8000 6 1200
7 0000 8 0000 9 0000 10 0000 11 0000 12 0008 13 1A2B
14 D637 15 4080 16 0000 17 0008 18 OCC8 19 0008 20 1F88
21 0008 22 1308 23 0008 24 0018 25 0008 26 0030 27 0008
28 0028 29 0008 30 0038 31 0008 32 FFFF 33 FDFF 34 0040
35 0008 36 0018 37 0008 38 FFFF 39 FDFF 40 F9C0 41 8308
42 FFC4 43 0308 44 F9C0 45 8308 46 3CFD 47 FFFF 48 FFFF
49 FFFF 50 FFFF 51 FFFF 52 DFFF 53 7EFF 54 FFFF 55 FFFD
56 EFFF 57 FFFF 58 FFFF 59 EFFF 60 0038 61 0008 62 F000
63 8308 64 1F88 65 0008 66 FFC4 67 0308 68 8000 69 0235
70 0202 71 0000 72 FFFC 73 FFFF 74 FFFF 75 FFFF 76 FFFC
77 FFFF 78 FFFE 79 FFFF 80 E810 81 FFFF 82 0000 83 FFFF
84 0038 85 0008 86 F000 87 FFFF 88 3003 89 2000 90 FFFF
91 FFFF 92 FFFE 93 FFFF 94 0235 95 FFFF 96 1308 97 8308
98 F9C0 99 0235 100 FFFF 101 FFFF 102 FFFF 103 FFFF 104 0000
105 0202 106 FFFF 107 FFFF 108 8000 109 0235 110 FFFF 111 FFFF
112 0000 113 FFFF 114 00A2 115 FFFF 116 FFFF 117 FFFF 118 FFFF
119 FFFF 120 FFFF 121 FFFF 122 FFFF 123 FFFF 124 FC00 125 FFFF
126 0000

Ethernet Controller ISACSR0 ... 7
0 0005 1 0005 2 0003 3 0000 4 0000 5 0084 6 0008 7 0090
```

## User Commands

### eshow

### eshow

The **eshow** command displays all of the registered Ethernet devices.

### Format

**eshow**

### Parameters

None.

### Description

The **eshow** command displays all of the installed device drivers and works for all of the motherboards. To set the Debug Monitor to use one of these devices, see the **edevic** command. An asterisk following the net device number indicates the selected Ethernet device to be used by the Debug Monitor Ethernet commands.

### Example

```
EB64> eshow
```

```
All registered Ethernet devices:
```

Net Device	Type
0	AM79C960
1	WD3003
2	Digital Semiconductor 21040
3*	Digital Semiconductor 21040

## estat

The **estat** command displays Ethernet statistics.

## Format

**estat**

## Parameters

None.

## Description

The **estat** command displays Ethernet statistics kept by the Ethernet device driver.

## Example

```
EB64> estat
      secs:                7          mc bytes rcv: 130075
      bytes rcv:          1297171      mc frms rcv:   625
      bytes snt:           0          frms snt dfrd:    0
      frms rcv:           3129        frms snt - cllsn:  0
      frms snt:           0          frms snt - mult cllsn: 0
      snd flrs - xs cllsn: 0          snd flrs - def:   0
      snd flrs - cc:       0          rcv flrs - fcs:   0
      snd flrs - shrt:     0          rcv flrs - ferr:  0
      snd flrs - opn:      0          rcv flrs flen:   0
      snd flrs - flen:     0          data ovrn:      0
      cllsn chk flr:      0
```

## User Commands

### estop

### estop

The **estop** command stops the Ethernet controller.

### Format

**estop**

### Parameters

None.

### Description

The **estop** command allows you to stop sending or receiving packets from an Ethernet device selected with the **edev** command.

### Example

```
EB66> eshow
All registered Ethernet devices:

      Net      Type
      Device
      0*      Digital Semiconductor 21040
      1      AM79C960
EB66> edev
Using network device 0
EB66> estop

Stopping network device 0 in PCI slot 20:
```

## fill

The **fill** command fills a specified memory block with the specified 32-bit pattern.

### Format

```
fill start_address end_address [fill_value]
```

### Parameters

#### **start\_address**

Specifies the start address for the fill value.

#### **end\_address**

Specifies the end address for the fill value. The fill value includes the end\_address.

#### **fill\_value**

Specifies a longword hexadecimal number as the fill value for the specified address. The default is 0.

### Description

The **fill** command fills a specified block of memory with a specified value. The data or fill value specified is placed in memory starting at the first address specified, and it fills through the last (or end) address specified.

## User Commands

### fill

### Example

This example displays the original value in address range 08000000 through 08000080 and the value of the same address range after the **fill** command.

```
EB64> p1 8000000
08000000: E7E01021 00000000 00000000 00000000 !.....
08000010: 00000000 00000000 00000000 00000000 .....
08000020: E7E01095 00000000 00000000 00000000 .....
08000030: 00000000 00000000 00000000 00000000 .....
08000040: 00000000 00000000 00000000 00000000 .....
08000050: 00000000 00000000 00000000 00000000 .....
08000060: 00000000 00000000 00000000 00000000 .....
08000070: 00000000 00000000 00000000 00000000 .....
EB64> fill 8000000 8000080 1f1f1f1f
EB64> p1 8000000 8000080
08000000: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000010: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000020: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000030: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000040: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000050: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000060: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000070: 1F1F1F1F 1F1F1F1F 1F1F1F1F 1F1F1F1F .....
08000080: 1F1F1F1F 00000000 00000000 00000000 .....
```

## flash

The **flash** command programs data into flash memory.

### Format

**flash** [source\_address [destination\_offset [bytes\_to\_write]]]

### Parameters

#### source\_address

Specifies the address in memory of the data to be programmed into the flash. The default is the default boot address (see **bootadr**).

#### destination\_offset

Specifies the offset, in bytes, into the flash where the first byte of source data will be programmed. If not provided, you are prompted with a default `destination_offset` value. The `destination_offset` combined with the size the data to be written must fit within the remaining space in the flash. Also note that ROM images containing the standard Makerom header must be longword aligned. See the MAKEROM chapter of the *Alpha Microprocessors Motherboard Software Design Tools User Guide*.

#### bytes\_to\_write

Specifies how many bytes to write beginning at the `source_address`. This parameter causes the flash command to ignore any standard header that might be included in the source data. This value defaults to the value in the image size field of the standard header. If not specified and if there is no standard image at the beginning of the source data, this value is assumed to be the remaining space in the flash.

### Description

The **flash** command programs the flash memory on the motherboards containing this type of memory. It reads data from memory at the specified source address and programs it into the flash at the specified offset. The amount of data written can be specified by the user or determined by the **flash** command.

## User Commands

### flash

### Example

```
AlphaPC 64> netload pc64dbm.rom
Attempting BOOTP...
Loading /users/eval/pc64/pc64dbm.rom at 300000
  My IP address:      16.123.45.67
  Server IP address: 16.123.45.69
#####File loaded
AlphaPC 64> flash
Image source address : 0x300000
Standard image header: Found.
  Header Size..... 56 bytes
  Image Checksum..... 0x6eeb (28395)
  Memory Image Size... 0x30B2C (199468 = 194 KB)
  Compression Type... 0
  Image Destination... 0x0000000000300000
  Header Version..... 2
  Firmware ID (Opt.).. 0 - Alpha Evaluation Board Debug Monitor
  FROM Image Size..... 0x30B2C (199468 = 194 KB)
  Firmware ID (Opt.).. 0200009511221015 .."....
  ROM offset..... 0x00000000
  Header Checksum..... 0x71fb
```

Enter destination offset or press RETURN for default [0]:

```
Flash offset          : 0x0
Image size w/ header : 199524 (Segment 0 to 3 inclusive).
```

```
!!!! Warning: About to overwrite flash memory !!!!
          Press Y to proceed, any other key to abort.
```

Update canceled by user.

```
AlphaPC 64> flash
Image source address : 0x300000
Standard image header: Found.
  Header Size..... 56 bytes
  Image Checksum..... 0x6eeb (28395)
  Memory Image Size... 0x30B2C (199468 = 194 KB)
  Compression Type... 0
  Image Destination... 0x0000000000300000
  Header Version..... 2
  Firmware ID.....0 - Alpha Evaluation Board Debug Monitor
  ROM Image Size..... 0x30B2C (199468 = 194 KB)
  Firmware ID (Opt.).. 0200009511221015 .."....
  ROM offset..... 0x00000000
  Header Checksum..... 0x71fb
```

Enter destination offset or press RETURN for default [0]: 40000

```
Flash offset          : 0x40000
Image size w/ header : 199524 (Segment 4 to 7 inclusive).
```

```
!!!! Warning: About to overwrite flash memory !!!!
```



## User Commands flash

Press Y to proceed, any other key to abort.

```
Writing Flash Block: 4W 5W 6W 7W
Verifying Flash Block: 4V 5V 6V 7V
AlphaPC 64> romlist
ROM image header found at offset: 0x040000
Header Size..... 56 bytes
Image Checksum..... 0x6eeb (28395)
Memory Image Size... 0x30B2C (199468 = 194 KB)
Compression Type.... 0
Image Destination... 0x0000000000300000
Header Version..... 2
Firmware ID..... 0 - Alpha Evaluation Board Debug Monitor
ROM Image Size..... 0x30B2C (199468 = 194 KB)
Firmware ID (Opt.).. 0200009511221015 .."....
ROM offset..... 0x00000000
Header Checksum..... 0x71fb
```

```
! Change the Image Destination field from 300000 to 400000
! Note that because no changes were performed to the Header
! Checksum field after the change, a header checksum
! error will be reported with romlist.
```

```
AlphaPC 64> dml 500000 400000
AlphaPC 64> flash 500000 40018 4
Image source address : 0x500000
```

```
Flash offset          : 0x40018
Data image size       : 4 (Segment 4 to 4 inclusive).
```

```
!!!! Warning: About to overwrite flash memory !!!!!
Press Y to proceed, any other key to abort.
```

```
Writing Flash Block: 4W
Verifying Flash Block: 4V
AlphaPC 64> romlist
ROM image header found at offset: 0x040000
Header Size..... 56 bytes
Image Checksum..... 0x6eeb (28395)
Memory Image Size... 0x30B2C (199468 = 194 KB)
Compression Type.... 0
Image Destination... 0x0000000000400000
Firmware ID..... 0 - Alpha Evaluation Board Debug Monitor
ROM Image Size..... 0x30B2C (199468 = 194 KB)
Firmware ID (Opt.).. 0200009511221015 .."....
ROM offset..... 0x00000000
Header Checksum..... 0x71fb
ERROR: Bad ROM header checksum. 0x79fb
```

## User Commands

### flasherase

## flasherase

The **flasherase** command erases data from flash memory.

### Format

**flasherase** [starting\_offset [bytes\_to\_erase]]

### Parameters

#### starting\_offset

Specifies the offset, in bytes, into the flash where data will be erased. If not provided, the entire flash will be erased.

#### bytes\_to\_erase

Specifies how many bytes to erase. If not specified, all bytes from the starting\_offset through the rest of the flash will be erased.

### Description

The **flasherase** command clears flash memory on boards equipped with flash. The area to be erased, that is, filled with zeros, can be specified or calculated by the **flasherase** command.

### Example

```
AlphaPC164> romlist
ROM image header found at offset: 0x000000
  Header Size..... 0x38 (56) bytes
  Image Checksum..... 0x45b0 (17840)
  Memory Image Size... 0xBA40 (47680 = 46 KB)
  Compression Type.... 0
  Image Destination... 0x0000000000300000
  Header Version..... 2
  Firmware ID..... 6 - Alpha Evaluation Board Fail-Safe Booter
  ROM Image Size..... 0xBA40 (47680 = 46 KB)
  Firmware ID (Opt).. 0202009702121228 (.....)
  ROM offset..... 0x00000000
  Header Checksum..... 0xfad4

ROM image header found at offset: 0x010000
  Header Size..... 0x38 (56) bytes
  Image Checksum..... 0xc63c (50748)
  Memory Image Size... 0x280B4 (164020 = 160 KB)
```

## User Commands

### flasherase

```
Firmware ID (Opt.).. 0202009706130904 .....
ROM offset..... 0x00000000
Header Checksum..... 0x94a5
AlphaPC164> flasherase 40000
Flash offset      : 0x40000
Bytes to be erased : 786432 (Block 4 to 15 inclusive).
      !!!!! Warning: About to overwrite flash memory !!!!!
      Press Y to proceed, any other key to abort.
Writing Flash Block: 4V 5V 6V 7V 8V 9V 10V 11V 12V 13V 14V 15V
```

## User Commands

### flboot

#### flboot

The **flboot** command downloads the specified file from the diskette and begins execution of that file.

#### Format

**flboot** file [address]

#### Parameters

##### file

Specifies the name of the file to access on the diskette.

##### address

Specifies the address at which to load the file. The default is the boot address.

#### Description

The **flboot** command downloads the specified file into the specified address or the boot address. The downloaded file automatically begins execution in PALmode as if a **jtopal** command had been entered.

#### Example

```
EB64> flboot size2
High Density selected

size2      .                20 bytes  11/21/1991 13:42:20
loading...
cluster:   2 sector:  33 buffer:  200000
done...
Jumping to 0x200000...
```

## fcd

The **fcd** command displays or changes the current working directory or drive.

### Format

**fcd** [drive\_pathname]

### Parameters

#### **drive\_pathname**

Specifies the new drive and working directory.

### Description

The **fcd** command allows you to change the current working directory for the current drive. It can also be used to switch to a different default drive. If no parameters are specified, then the default drive and working directory are displayed.

Drives are specified by using the letters A through Z. The path is a list of subdirectories separated by a slash (/) for DIGITAL UNIX users or a backslash (\) for DOS users. The top-level directory (known as the root directory) is represented by a slash (/) or backslash (\). A path can be an absolute or relative path. An absolute path begins with the root directory, whereas a relative path begins with the current working directory.

Subdirectory entries also contain two special entries that can be used to specify a path. One period (.) represents the current directory and two periods (..) represent the directory above the current level.

## User Commands

### flcd

### Example

```
AlphaPC 64> flcd
a:\
AlphaPC 64> fldir
High Density selected
10/04/95 02:07p                203088 rom.cmp
10/04/95 02:08p                203140 rom.rom
10/06/95 10:05a                <DIR>    dir1
10/06/95 10:05a                <DIR>    dir3
                                1048576 bytes free

AlphaPC 64> flcd dir1
a:\dir1\
AlphaPC 64> fldir
High Density selected
10/06/95 10:05a                <DIR>    .
10/06/95 10:05a                <DIR>    ..
10/06/95 10:05a                <DIR>    dir2
                                1048576 bytes free

AlphaPC 64> flcd /dir1/dir2
a:\dir1\dir2\
AlphaPC 64> fldir
High Density selected
10/06/95 10:05a                <DIR>    .
10/06/95 10:05a                <DIR>    ..
                                1048576 bytes free

AlphaPC 64> flcd ../../dir3
a:\dir1\dir2\..\..\dir3\
AlphaPC 64> fldir
High Density selected
10/06/95 10:05a                <DIR>    .
10/06/95 10:05a                <DIR>    ..
04/28/95 05:59p                71 diff.lst
                                1048576 bytes free

AlphaPC 64> flcd b:
b:\
AlphaPC 64> fldir
High Density selected
09/07/95 10:28a                6688 srom
10/03/95 05:59p                202980 rom.rom
                                1247232 bytes free
```

## fcopy

The **fcopy** command copies a file to another location.

### Format

```
fcopy source_file destination_file
```

### Parameters

#### **source\_file**

Specifies the file to be copied. If no drive and path are specified, the default drive and path are used.

#### **destination\_file**

Specifies the name of the copied file. If no drive and path are specified, the default drive and path are used. Note that a destination file name must always be specified, even if copying to a subdirectory.

### Description

The **fcopy** command allows you to copy a file to another destination. An optional drive and path specification may be specified for either the source or destination file name. If they are not specified, then the default drive and path are used.

## User Commands

### flcopy

### Example

```
AlphaPC 64> flcd \dir3
a:\dir3\
AlphaPC 64> fldir
High Density selected
10/06/95  10:05a          <DIR>      .
10/06/95  10:05a          <DIR>      ..
04/28/95  05:50p                71 diff.lst
                                1048064 bytes free

AlphaPC 64> flcopy diff.lst ..\dir1\dir2\diff2.lst
High Density selected
Copying files...
Done...
AlphaPC 64> fldir ..\dir1\dir2\
High Density selected
10/06/95  10:05a          <DIR>      .
10/06/95  10:05a          <DIR>      ..
10/06/95  10:48a                71 diff2.lst
                                1047552 bytes free

AlphaPC 64> flcopy diff.lst b:\diff2.lst
High Density selected
High Density selected
Copying files...
Done...
AlphaPC 64> fldir b:\
High Density selected
09/07/95  10:28a                6688 srom
10/03/95  05:59p                202980 rom.rom
10/06/95  10:53a                71 diff2.lst
                                1246720 bytes free
```



## fdir

The **fdir** command displays a list of files in the current or specified directory.

### Format

**fdir** [drive\_pathname]

### Parameters

#### **drive\_pathname**

Specifies the drive or subdirectory.

### Description

The **fdir** command displays a directory of files in the current or specified directory.

Drives are specified by using the letters A through Z. The path is a list of subdirectories separated by a slash (/) for DIGITAL UNIX users or a backslash (\) for DOS users. The top-level directory (known as the root directory) is represented by a slash (/) or backslash (\). A path can be an absolute or relative path. An absolute path begins with the root directory, whereas a relative path begins with the current working directory.

Subdirectory entries also contain two special entries that can be used to specify a path. One period (.) represents the current directory and two periods (..) represent the directory above the current level.

## User Commands

### fdir

### Example

```
AlphaPC 64> flcd
a:\

AlphaPC 64> fdir
High Density selected
10/04/95  02:07p                203088 rom.cmp
10/04/95  02:08p                203140 rom.rom
10/06/95  10:05a                <DIR>     dir1
10/06/95  10:05a                <DIR>     dir3
                                   1048064 bytes free

AlphaPC 64> fdir /dir1
High Density selected
10/06/95  10:05a                <DIR>     .
10/06/95  10:05a                <DIR>     ..
10/06/95  10:05a                <DIR>     dir2
                                   1048064 bytes free

AlphaPC 64> flcd dir1\dir2
a:\dir1\dir2\
AlphaPC 64> fdir ..\..\dir3
High Density selected
10/06/95  10:05a                <DIR>     .
10/06/95  10:05a                <DIR>     ..
04/28/95  05:50p                71 diff.lst
                                   1048064 bytes free

AlphaPC 64> fdir b:\
High Density selected
09/07/95  10:28a                6688 srom
10/03/95  05:59p                202980 rom.rom
                                   1247232 bytes free
```

## fload

The **fload** command downloads the specified file from the diskette.

### Format

**fload** file [address]

### Parameters

#### file

Specifies the name of the file to access on the diskette.

#### address

Specifies the address at which to load the file. The default is the boot address.

### Description

The **fload** command downloads the specified file into the specified address or the boot address. The program can then be executed with the **go** or **jtopal** commands.

### Example

```
EB64> bootadr
00200000
EB64> fload size2
High Density selected

size2      .                20 bytes  11/21/1991 13:42:20
loading...
cluster:   2 sector:  33 buffer:  200000
done...
```

## User Commands

### flread

### flread

The **flread** command reads logical sectors from a diskette.

### Format

**flread** [first\_sector [bytes [dest\_address [iterations [drive]]]]]

### Parameters

#### **first\_sector**

Specifies the first logical sector of diskette to read. The default is sector 0 (the boot sector).

#### **bytes**

Specifies the number of bytes to be read from the diskette. The default sector is one sector.

#### **dest\_address**

Specifies the beginning address where data will be loaded. The default is the boot address.

#### **iterations**

Specifies the number of times to repeat the reading of the sector range. The default is 1.

#### **drive**

Specifies the diskette drive number to use: 0 or 1. The default is 0.

### Description

The **flread** command reads the data from the specified logical sectors of a diskette into memory. The iterations parameter can be used to repeat the task a specified number of times.

## Example

```
AlphaPC164> fread 1
High Density selected
Reading 0 bytes to 0x300000 starting at sector 1.
Done... 512 (0X200) bytes transferred
AlphaPC164> fread 1 1500
High Density selected
Reading 1500 bytes to 0x300000 starting at sector 1.
Done... 1536 (0X600) bytes transferred
AlphaPC164> fread 1 1500 400000
High Density selected
Reading 1500 bytes to 0x400000 starting at sector 1.
Done... 1536 (0X600) bytes transferred
AlphaPC164> fread 1 1500 400000 3
High Density selected
Reading 1500 bytes to 0x400000 starting at sector 1.
Done... 1536 (0X600) bytes transferred
      2 iterations remaining
Done... 1536 (0X600) bytes transferred
      1 iterations remaining
Done... 1536 (0X600) bytes transferred
```

## User Commands

### flsave

### flsave

The **flsave** command writes a memory range to a file.

### Format

**flsave** file\_name start\_address file\_size

### Parameters

#### file\_name

Specifies the name of the file to be created with the data. If no drive or path is specified, the file is created in the default working directory.

#### start\_address

Specifies the address in memory to start writing to the file.

#### file\_size

Specifies the size in bytes of the file to write.

### Description

The **flsave** command writes a section of memory to a file. The file name can specify a drive and path.

### Example

```
AlphaPC164> flsave test.txt 300000 34526
High Density selected
Saving range 0x300000 to 0x334525 to file test.txt
AlphaPC164> flsave b:\test.txt 300000 34526
High Density selected
Saving range 0x300000 to 0x334525 to file b:\test.txt
```

## flwrite

The **flwrite** command writes data to logical sectors on a diskette.

**Caution:** This is a destructive command. You must be careful which sectors you write to because you may render the disk unusable.

## Format

**flwrite** [first\_sector [image\_size [source\_address [iterations [drive]]]]]

## Parameters

### first\_sector

Specifies the first logical sector of diskette to be written. The default is sector 0 (the boot sector).

### image\_size

Specifies the number of bytes to write to the diskette. The default is one sector.

### source\_address

Specifies the beginning address where data to be written resides. The default is the boot address.

### iterations

Specifies the number of times to repeat the writing of the sector range. The default is 1.

### drive

Specifies the diskette drive number to use: 0 or 1. The default is 0.

## Description

The **flwrite** command writes data from memory to the specified logical sectors of a diskette.

The iterations parameter can be used to repeat the task a specified number of times.

## User Commands

### flwrite

### Example

```
AlphaPC164> flwrite 30  
High Density selected  
Writing 0 bytes from 0x400000 starting at sector 30.  
Done... 512 (0X200) bytes transferred  
AlphaPC164> flwrite 30 3400  
High Density selected  
Writing 3400 bytes from 0x400000 starting at sector 30.  
Done... 3584 (0XE00) bytes transferred  
AlphaPC164> flwrite 30 3400 300000  
High Density selected  
Writing 3400 bytes from 0x300000 starting at sector 30.  
Done... 3584 (0XE00) bytes transferred  
AlphaPC164> flwrite 30 3400 300000 2  
High Density selected  
Writing 3400 bytes from 0x300000 starting at sector 30.  
Done... 3584 (0XE00) bytes transferred  
1 iterations remaining  
Done... 3584 (0XE00) bytes transferred
```



## fwupdate

The **fwupdate** command loads and runs the firmware update utility from diskette.

### Format

**fwupdate**

### Parameters

None.

### Description

The **fwupdate** command loads and executes the firmware update utility (fwupdate.exe) from diskette. The utility gets loaded into physical address  $900000_{16}$  (physical location 9 MB), and gets executed in PALmode.

This command expects the diskette to be formatted with a FAT file structure.

### Example

```
AlphaPC 64> fwupdate  
...follow instructions to update firmware for  
Windows NT Firmware, the Debug Monitor, or the Alpha SRM Console ...
```

## User Commands

### go

### go

The **go** command begins execution of instructions at the specified address.

### Format

```
go [start_address]
```

### Parameters

#### **start\_address**

Specifies the address at which to start executing the instructions.

### Description

The **go** command jumps to a location in memory and begins executing instructions. If no address is specified, then the execution of instructions begins at the boot address.

### Example

This example starts executing instructions at address  $100000_{16}$ .

```
EB64> go 100000
```

## help

The **help** command displays a list of commands currently available. If you specify a command keyword, information about the specified command is displayed.

### Format

**h[elp]** [command\_keyword]

### Parameters

#### **command\_keyword**

Indicates any command name that appears in the list when you type the **help** command. An asterisk (\*) displays help for all commands.

### Description

The **help** command displays a list of command keywords implemented in the current release. The command can be abbreviated to one letter, **h**. If you specify a command with a command keyword, then a brief description and syntax for the specified command is displayed. You can use an asterisk (\*) in place of a command keyword to display all help information.

## User Commands

### help

### Example

The **help** command without a parameter displays a list of all commands implemented in the current version of the software. When specified with a parameter, it displays more information about that command keyword.

```
AlphaPC164LX> help
```

```
A brief help description is available for each of the following commands.
```

load	boot	netload	netboot	flcd	flcopy
fldir	flboot	flload	flread	flwrite	flsave
romboot	romlist	romload	romverify	bootadr	go
jtopal	init	eml	emq	dml	dmq
pq	pl	pw	pb	cq	cl
cw	cb	fill	copy	compare	dis
rl	rw	rb	wl	ww	wb
wb	mrl	mrw	mrw	mwl	mww
mwb	sq	sl	sw	sb	pcishow
prl	prw	prb	pwl	pww	pwb
flash	flasherase	fwupdate	date	apropos	help
h	ident	version	sysshow	swpipl	mces
wrfen	preg	pfreg	creg	cfreg	stop
bpstat	next	n	step	s	cont
delete	ladebug	riccsr	wiccsr	rbctl	wbctl
rbcfg	wbcfg	iack	rmode	setty	setbaud
tip	edevice	eshow	ereg	estat	einit
estop	ebuff	edmp	eprom	arpshow	mcheck
beep	mementest				

```
Hit any key to continue. Control-C to quit...
```

```
AlphaPC164LX> help *
```

```
Displays help for all commands in the command list.
```

## iack

The **iack** command performs an interrupt acknowledge cycle.

### Format

**iack**

### Parameters

None.

### Description

The **iack** command allows you to perform an interrupt acknowledge cycle. Two **iack** commands are required to read the interrupt vector.

### Example

```
EB64> iack  
FF  
EB64> iack  
07
```

## User Commands

### ident

### ident

The **ident** command displays revision control system (RCS) ID strings found in the specified memory range.

### Format

**ident** [start\_address [end\_address]]

### Parameters

#### **start\_address**

Specifies a hexadecimal number that represents a legal address at which to start searching for RCS keywords. The default value is the boot address.

#### **end\_address**

Specifies a hexadecimal number that represents a legal address at which to end the search for RCS keywords. The default value is the boot address plus  $70_{16}$ .

### Description

The **ident** command identifies the revision of files used to build images that were loaded into memory by searching for all occurrences of the pattern \$keyword: ...\$ in the specified memory range. This command is based on the assumption that RCS was used for version control on the source files on the host development system. RCS is supplied with the DIGITAL UNIX operating system.

## Example

```
EB64> ident 0 80000
Id: crt_startup.s,v 1.3 1993/06/18 20:30:03 fdh Rel $
Id: crt.c,v 1.1 1993/06/08 19:56:39 fdh Rel $
Id: dis.c,v 1.1 1993/06/08 19:56:40 fdh Rel $
Id: ffexec.c,v 1.2 1993/06/09 20:23:05 fdh Rel $
Id: ffsrec.c,v 1.1 1993/06/08 19:56:41 fdh Rel $
Id: cmd.c,v 1.6 1993/06/18 17:32:36 fdh Rel $
Id: pReg.c,v 1.1 1993/06/08 19:56:41 fdh Rel $
Id: rw.c,v 1.1 1993/06/08 19:56:42 fdh Rel $
Id: netboot.c,v 1.1 1993/06/08 19:56:30 fdh Rel $
Id: amd.c,v 1.2 1993/06/08 22:32:57 berent Rel $
Id: tftp.c,v 1.1 1993/06/08 19:56:31 fdh Rel $
Id: netutil.c,v 1.1 1993/06/08 19:56:31 fdh Rel $
Id: boots.c,v 1.2 1993/06/08 22:32:57 berent Rel $
Id: listener.c,v 1.2 1993/06/08 22:32:57 berent Rel $
Id: kernel.c,v 1.5 1993/06/18 17:49:34 fdh Rel $
Id: bptable.c,v 1.1 1993/06/08 19:56:33 fdh Rel $
Id: kutil.s,v 1.1 1993/06/08 19:56:36 fdh Rel $
Id: comms.c,v 1.2 1993/06/08 22:32:06 berent Rel $
Id: server_read_loop.c,v 1.1 1993/06/08 19:56:38 fdh Rel $
Id: packet-handling.c,v 1.2 1993/06/08 22:32:06 berent Rel $
Id: printf.c,v 1.1 1993/06/08 19:56:24 fdh Rel $
```

Hit any key to continue. Control-C to quit...

## User Commands

### init

### init

The **init** command reinitializes the Debug Monitor.

### Format

**init**

### Parameters

None.

### Description

The **init** command restarts the Debug Monitor by jumping to the PALcode base address in PALmode. It is analogous to using the **jtopal** command with the PALbase address.

### Example

```
AlphaPC 64> init  
Stopping network device 0 in PCI slot 18:  
Jumping to 0x000000...  
===== Starting Debug Monitor!!! =====
```



## jtopal

The **jtopal** command sets the environment to PALmode and begins execution of instructions at the specified address.

### Format

```
jtopal [start_address]
```

### Parameters

#### **start\_address**

Specifies the address at which to start executing instructions. The default is the boot address.

### Description

The **jtopal** command emulates the hardware mechanism for entering PALcode. When instructions contain PALcode, you must set the environment to PALmode to properly execute instructions. This command is required for executing downloaded images entered in PALmode, such as a serial ROM or debug ROM image. The **jtopal** command sets the environment to PALmode and then jumps to the specified location in memory to begin executing instructions.

### Example

This example starts executing instructions at address  $100000_{16}$ .

```
EB64> jtopal 100000
```

## User Commands

### ladebug

#### ladebug

The **ladebug** command starts the Ladebug server for a remote debug session.

#### Format

**ladebug**

#### Parameters

None.

#### Description

The **ladebug** command configures the motherboard as a remote debugger target. You can connect to the motherboard from the Ladebug source-level debugger running on a DIGITAL UNIX host. Communication is performed through the Ethernet connection. The Ladebug software provides the full source-level debugging capabilities of most programs running on the motherboard, including the Debug Monitor.

To debug a program running on a motherboard using Ladebug running on a remote host, follow these steps:

1. Load the program into memory on the motherboard.
2. Set a breakpoint in the program.
3. Execute the program. The program will stop at the breakpoint and print the instruction line at that location.
4. Issue the **ladebug** command. This causes the motherboard to wait for a connection from Ladebug.
5. From the host system, enter the command to start up Ladebug and cause it to connect to the motherboard.

Refer to the Ladebug documentation for more information.

## Example

```
EB64> netload size
Ethernet Base Address: 360, DMA Mask: 1 = DRQ5
Init Block Address 100000
Init Done.
Ethernet BA-98-76-54-32-10
Attempting BOOTP...success.
    my IP address: 16.123.45.67
    server IP address: 16.123.45.69
    gateway IP address: 16.123.45.69
Loading from /users/eval/boot/size ...
####
EB64> stop 200000
EB64> go
Executing at 0x200000...

00200000: 23DEFFF0          lda    sp, -16(sp)
EB64> ladebug
Ethernet Base Address: 360, DMA Mask: 1 = DRQ5
Init Block Address 100000
Init Done.
Client connected : client is FFFFFFFFA0107F10
```

The following command, entered from the host system, starts Ladebug and causes it to connect to the EB64:

```
% ladebug size.out -rn eb64 -pid 0
```

The following information is displayed on the host system:

```
Welcome to the Ladebug Debugger Version 1.3.1
-----
object file name: size.out
machine name: eb64
process id: 0
Reading symbolic information ...done
Connected to remote debugger
(ladebug)
```

The (ladebug) in the previous example is the Ladebug prompt. You are now ready to debug a process that is running on the EB64.

## User Commands

### load

### load

The **load** command downloads a file through the active serial port using the XMODEM protocol.

### Format

**load** [address]

### Parameters

#### address

Specifies the address at which to download the file. The default is the boot address.

### Description

The **load** command uses the XMODEM protocol to download a file through the active serial port. The program is loaded to the supplied address or the boot address if an address is not specified. The program can then be executed with the **go** or **jtopal** commands.

### Example

In this example, a DIGITAL UNIX host system is connected to the motherboard on device `/dev/tty01`. The `sx` command sends a file using XMODEM.

```
% echo load 300000 > /dev/tty01
% sx -kt 10 /users/eval1/demo2/size </dev/ttya01 >/dev/tty01
Sector nnn
%tip /dev/tty01
AlphaPC164>
```

## mces

The **mces** command sets or displays the machine check error summary register.

### Format

```
mces [mces_data]
```

### Parameters

**mces\_data**

Specifies the value to be written to the machine check error summary register.

### Description

The machine check error summary register controls machine check and system-correctable error handling. The **mces** command provides direct user access to the `rdmces` and `wrmces` PALcode instructions that are defined by the *Alpha AXP Architecture Reference Manual*.

This register is also affected by the **mcheck** command.

### Example

In the following example, a zero is written to the machine check error summary register:

```
EB164> mces  
Machine Check Error Summary: 08  
EB164> mces 0  
Machine Check Error Summary: 00
```

## User Commands

### mcheck

#### mcheck

The **mcheck** command controls the reporting of hardware error conditions (machine checks).

#### Format

**mcheck** state

#### Parameters

**state = on**

Enables all machine check reporting.

**state = off**

Disables all machine check reporting.

**state = system**

Enables machine check reporting for hardware errors detected external to the CPU.

**state = cpu**

Enables machine check reporting for hardware errors detected by the CPU.

#### Description

The **mcheck** command controls the reporting of hardware error conditions. A machine check indicates that a hardware error condition was detected. Different error conditions are detected by the CPU or system logic external to the CPU. To help to ensure the availability of the Debug Monitor for hardware debug, machine check reporting is disabled when the Debug Monitor starts up. This condition makes the Debug Monitor firmware more fail-safe than conventional firmware when hardware integrity is questionable. Therefore, when using the Debug Monitor, machine checks can be enabled on demand by the **mcheck** command to facilitate low-level hardware debug.

Because some machine checks are reported through interrupt requests at interrupt priority level (IPL) 6, the **mcheck** command could change the current IPL. If the current IPL is lower than 7, the current IPL will not be affected. See the description of the **swpipl** command for more information about the IPL.

The **mcheck** command could also modify the machine check error summary register. See the **mces** command for more information about the machine check error summary register.

## Example

In the following example, all machine check and correctable error reporting are enabled before running the memory test. The errors displayed in this example are correctable, and without machine checks enabled, these memory errors would be corrected by the CPU.

```
EB164> mcheck on
Old BC_CTL = 0x00028051 & BC_CFG = 0x01E21772
New BC_CTL = 0x00020041 & BC_CFG = 0x01E21772
CIA_CACK_EN = 0x8 & CIA_MCR = 0x2001FE21
EB164> mces
Machine Check Error Summary: 00
EB164> memtest
Walking 1's ... range 0x0008a420:0x03ffc000
Processor Correctable Machine Check: Interrupt vector = 0x630
      EI_STAT: FFFFFFF0C4FFFFFF      EI_ADDR: FFFFFFF00001231AF
FILL_SYNDROME: 0000000000000019      ISR: 0000000100600000
Processor Correctable Machine Check: Interrupt vector = 0x630
      EI_STAT: FFFFFFF0C4FFFFFF      EI_ADDR: FFFFFFF00009231AF
FILL_SYNDROME: 0000000000000019      ISR: 0000000100600000
```

## User Commands

### memtest

#### memtest

The **memtest** command tests a memory range.

#### Format

```
memtest [iterations] [start_address] [end_address] [increment] [mcheck] [stop_drivers]
```

#### Parameters

##### iterations

Specifies the number of times the memory range test will run. The default iteration is 1.

##### start\_address

Specifies the address at which to start the memory test. The default is the current address.

##### end\_address

Specifies the address at which to end the memory test.

##### increment

Defines the step size. The default is longword access (4).

##### mcheck

Specifies the machine check state as defined by the **mcheck** command (see the **mcheck** command). The mcheck state is specified during the start of the memory test. Possible selections are: on, off, cpu, and system. The default is on.

##### stop\_drivers

Specifies if device drivers should be stopped before the start of the memory test. A nonzero value stops all device drivers. A zero value specifies that drivers should not be stopped. The default is stopped.

#### Description

The **memtest** command performs a set of memory tests on the specified address range. This test uses longword accesses to memory. The tests include walking 1s and walking 0s as well as alternating 1s and 0s.



While conducting the memory test, correctable read data errors may be encountered, indicating memory integrity problems. However, if hardware error reporting is disabled, the CPU corrects the correctable errors without reporting them. To alleviate this problem, the `mcheck` parameter must specify the machine check conditions while running the memory test.

Device drivers that use main memory for DMA access while the memory test is running may cause *unpredictable* results. To prevent the memory test from conflicting with the device drivers, the `stop_drivers` parameter must be set to a nonzero value.

### Example

```
EB64> memtest 2 8000000 8fffffff 4 on 1
```

## User Commands

### **mrb**

### **mrb**

The **mrb** command reads a byte from memory in the register port in I/O address space.

### **Format**

**mrb** address [iterations [silent]]

### **Parameters**

#### **address**

Specifies the address in memory I/O space.

#### **iterations**

Specifies how many times the data is read. The default is 1.

#### **silent**

Specifies whether or not the data is displayed. Setting this field to 1 causes the data to be read but not displayed. The default is 0 (data is displayed).

### **Description**

The **mrb** command displays the byte from the specified memory location in the memory I/O space. For example, on the EB64, the byte is read from the ISA extension slot.

### **Example**

```
EB64> mrb d0000
FF
```

## mrl

The **mrl** command reads a longword from memory in the register port in I/O address space.

### Format

**mrl** address [iterations [silent]]

### Parameters

#### address

Specifies the address in memory I/O space.

#### iterations

Specifies how many times the data is read. The default is 1.

#### silent

Specifies whether or not the data is displayed. Setting this field to 1 causes the data to be read but not displayed. The default is 0 (data is displayed).

### Description

The **mrl** command displays the longword from the specified memory location in the memory I/O space. For example, on the EB64, the longword is read from the ISA extension slot.

### Example

```
EB64> mrl d0000  
FC04FF00
```

## User Commands

### mrw

### mrw

The **mrw** command reads a word from memory in the register port in I/O address space.

### Format

**mrw** address [iterations [silent]]

### Parameters

#### address

Specifies the address in memory I/O space.

#### iterations

Specifies how many times the data is read. The default is 1.

#### silent

Specifies whether or not the data is displayed. Setting this field to 1 causes the data to be read but not displayed. The default is 0 (data is displayed).

### Description

The **mrw** command displays the word from the specified memory location in the memory I/O space. For example, on the EB64, the word is read from the ISA extension slot.

### Example

```
EB64> mrw d0000  
FF00
```

## mwb

The **mwb** command writes a byte to memory in the register port in I/O address space.

### Format

**mwb** address data [iterations]

### Parameters

#### address

Specifies the address in memory I/O space where the byte is written.

#### data

Specifies byte data.

#### iterations

Specifies how many times the data is read. The default is 1.

### Description

The **mwb** command specifies the memory location in I/O memory space to write data in byte format.

### Example

```
EB64> mrd d0000  
FF  
EB64> mwb d0000 0  
EB64> mrd d0000  
00
```

## User Commands

### **mw1**

### **mw1**

The **mw1** command writes a longword to memory in the register port in I/O address space.

### **Format**

**mw1** address data [iterations]

### **Parameters**

#### **address**

Specifies the address in memory I/O space where the longword is written.

#### **data**

Specifies longword data.

#### **iterations**

Specifies how many times the data is read. The default is 1.

### **Description**

The **mw1** command writes a longword to memory in I/O address space. For example, on the EB64, the longword is written to the ISA extension slot.

### **Example**

```
EB64> mw1 d0000 fc04ff00
```

## mww

The **mww** command writes a word to memory in the register port in I/O address space.

### Format

**mww** address data [iterations]

### Parameters

#### address

Specifies the address in memory I/O space where the word is written.

#### data

Specifies word data.

#### iterations

Specifies how many times the data is read. The default is 1.

### Description

The **mww** command writes a word to memory I/O space. For example, on the EB64, a word is written to the ISA extension slot.

### Example

```
EB64> mrw d0000  
FF00  
EB64> mww d0000 a5a5  
EB64> mrw d0000  
A5A5
```

## User Commands

### netboot

#### netboot

The **netboot** command downloads the specified file through the Ethernet port and begins execution of that file.

#### Format

```
netboot [file [address]]
```

#### Parameters

##### file

Specifies a legal file name to be downloaded to the motherboard. The default is to load the file specified in the `bootptab` file.

##### address

Specifies the address at which to download the file. The default is the boot address.

#### Description

The **netboot** command uses BOOTP to download the specified file through the Ethernet port. The Ethernet port is selected through the **edev** command. The downloaded file automatically begins execution in PALmode. This command has the same effect as using the **netload** command followed by the **jtopal** command.

A default file and directory path may be defined in the `bootptab` file. See Section 2.3.4.2 for more information.

If you specify an address, this address becomes the default boot address. This value, however, is not set in battery-backed RAM.



## Example

This example downloads and begins execution of a file called `size`.

```
EB64> netboot size
Ethernet Base Address: 360, DMA Mask: 1 = DRQ5
Init Block Address 80000
Init Done.
Ethernet BA-98-76-54-32-10
Attempting BOOTP...success.
    my IP address: 16.123.45.67
    server IP address: 16.123.45.69
    gateway IP address: 16.123.45.69
Loading from /users/eval/boot/size ...
###
Jumping to 0x100000...

char    = 1
short   = 2
int     = 4
long    = 8
float   = 4
double  = 8

Alpha 21064 Evaluation Board (EB64) Debug Monitor
Version: Wed Feb 10 19:52:24 EST 1993
Bootadr: 0x100000, memSize: 0x2000000
```

## User Commands

### netload

#### netload

The **netload** command downloads the specified file through the Ethernet port to the default boot address.

#### Format

**netload** [file [address]]

#### Parameters

##### file

Specifies a legal file name to be downloaded to the motherboard. The default is to load the file specified in the `bootptab` file.

##### address

Specifies the address at which to download the file. The default is the boot address.

#### Description

The **netload** command uses BOOTP to download the specified file through the Ethernet port. The Ethernet port is selected using the **edevic** command. The program is loaded into the default boot address. You can set up or change the boot address with the **bootadr** command. The program can then be executed with the **go** or **jtopal** command.

A default file and directory path may be defined in the `bootptab` file. See Section 2.3.4.2 for more information.

If you specify an address, this address becomes the default boot address. This value, however, is not set in battery-backed RAM.

## Example

In this example, a file called `size` is loaded into the default boot address.

```
EB64> netload size
Ethernet Base Address: 360, DMA Mask: 1 = DRQ5
Init Block Address 80000
Init Done.
Ethernet BA-98-76-54-32-10
Attempting BOOTP...success.
    my IP address: 16.123.45.67
    server IP address: 16.123.45.69
    gateway IP address: 16.123.45.69
Loading from /users/eval/boot/size ...
###
```

## User Commands

### next

### next

The **next** command executes the machine instruction without stepping into subroutines.

### Format

**n[ext]**

### Parameters

None.

### Description

Use the **step** command and the **next** command to execute a machine instruction. When the instruction contains a subroutine, the **step** command steps into the subroutine being called and the **next** command executes the subroutine being called.

## Example

In the following example, the **step** command used at address 200034 steps to the first instruction of the function being called at address 2000c0. The **next** command used at address 2000ec executes the function being called and steps to the next instruction at address 2000f0.

```

EB164> dis
00200030: a77d8010          ldq    r27, 32784(r29)
00200034: 6b5b4000          jsr    r26, r27
00200038: 27ba0001          ldah   r29, 1(r26)
0020003c: 23bdc148          lda    r29, 49480(r29)
EB164> step
00200030: a77d8010          ldq    r27, 32784(r29)
EB164> step
00200034: 6b5b4000          jsr    r26, r27
EB164> step
002000c0: 27bb0001          ldah   r29, 1(r27)
.
.
.
EB164> dis
002000e8: a77d8040          ldq    r27, 32832(r29)
002000ec: 6b5b46b8          jsr    r26, r27
002000f0: 27ba0001          ldah   r29, 1(r26)
EB164> step
002000e8: a77d8040          ldq    r27, 32832(r29)
EB164> step
002000ec: 6b5b46b8          jsr    r26, r27
EB164> next
002000f0: 27ba0001          ldah   r29, 1(r26)
EB164>

```

## User Commands

### pb

### pb

The **pb** command displays the specified memory byte (8-bit).

### Format

**pb** [start\_address [end\_address [iterations [silent]]]]

### Parameters

#### start\_address

Specifies a hexadecimal number that represents a legal address at which to start the display. The default is the current address.

#### end\_address

Specifies a hexadecimal number that represents a legal address at which to end the display. The default is the current address plus 127 bytes.

#### iterations

Specifies how many times the data is read. The default is 1.

#### silent

Specifies whether or not the data is displayed. Setting this field to 1 causes the data to be read but not displayed. The default is 0 (data is displayed).

### Description

The **pb** command displays the specified memory in byte format. If no address is specified, then the current memory byte and the following 127 bytes are displayed. The field displayed after the bytes represents the translation of the memory contents in ASCII characters. If the memory contents can be translated to an ASCII character, then that character is displayed; otherwise, a dot is displayed.

The silent and iterations fields are often used together to continuously perform read operations, thus, avoiding slowdowns caused by displaying the data. The repeating cycles can be monitored with test equipment.

## Example

This example displays 128 bytes from memory starting with 100000 in byte format.

```
EB64> pb 100000
00100000: 03 00 00 C1 00 00 00 00 10 D9 10 00 00 00 00 00 .....
00100010: 07 00 88 2F 00 00 9E A4 05 14 C1 43 06 14 A1 40 .../.....C...@
00100020: 22 77 80 48 06 04 C2 40 F0 82 DC B4 F8 82 9C B4 "w.H...@.....
00100030: 00 83 BC B4 3E 15 C5 43 20 00 FE B7 08 83 FC B3 ....>..C .....
00100040: 07 00 00 D0 04 04 E2 47 19 10 00 D0 80 00 00 00 .....G.....
00100050: 1F 04 FF 47 00 00 00 00 00 00 00 00 00 00 00 ...G.....
00100060: 3E 15 C6 43 28 00 1E B4 36 01 00 D0 18 80 9C A4 >..C(...6.....
00100070: 05 34 E0 43 09 03 00 D0 20 80 9C A4 05 54 E0 43 .4.C.... ....T.C
```

## User Commands

### pcishow

#### pcishow

The **pcishow** command displays the contents of each PCI slot and the current PCI-to-system address space mapping.

#### Format

**pcishow** bus id function

#### Parameters

##### bus

Specifies which bus to show. The default value is 0.

##### id

Specifies a decimal number that represents the slot assigned to the PCI device.

##### function

Specifies which function to read from. The default value is 0.

#### Description

The **pcishow** command applies only to PCI motherboards.



## Example

```
EB164> pcishow

PCI Address Mapping windows are:
    (1) PCI Base = 0x00100000, Size = 0x00100000
        Translated Base = 0x00100000

Bus = 0
    primary = 0, secondary = 0, subordinate = 0
    PCI I/O space = 1000, PCI Mem space = 3F00000
    PCI I/O base = B000, PCI Mem base = 200000
PCI slot 18, vendor = 0x1011, device = 0x4
    PCI IO Base = 0x0, PCI IO Size = 0x0
    PCI Mem Base = 0x2000000, PCI Mem Size = 0x2000000
    Display controller
PCI slot 19, vendor = 0x8086, device = 0x484
    PCI IO Base = 0x0, PCI IO Size = 0x0
    PCI Mem Base = 0x0, PCI Mem Size = 0x0
    Non-VGA compatible device
PCI slot 17, vendor = 0x1011, device = 0x2
    PCI IO Base = 0xB000, PCI IO Size = 0x80
    PCI Mem Base = 0x4000000, PCI Mem Size = 0x80
    Ethernet controller
PCI slot 20, vendor = 0x1000, device = 0x1
    PCI IO Base = 0xB400, PCI IO Size = 0x100
    PCI Mem Base = 0x4001000, PCI Mem Size = 0x100
    Non-VGA compatible device

EB164>
```

## User Commands

### pfreg

### pfreg

The **pfreg** command displays the saved CPU floating-point register state.

### Format

**pfreg** [address]

### Parameters

#### address

Specifies an alternate address for the saved-state area.

### Description

The **pfreg** command displays the contents of the CPU floating-point registers stored in the saved-state area. A register state is stored when a breakpoint is encountered or the PALcode reset flow is entered.

### Example

```
EB64> pfreg
Floating Point Registers
register file @: 0000C840
f00: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f04: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f08: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f12: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f16: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f20: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f24: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
f28: 0000000000000000 0000000000000000 0000000000000000 0000000000000000
PC: 000000000000000D PS: 000000000000000D
```

## pl

The **pl** command displays the specified memory longword (32-bit).

### Format

```
pl [start_address [end_address [iterations [silent]]]]
```

### Parameters

#### **start\_address**

Specifies a hexadecimal number that represents a legal address at which to start the display. The default is the current address.

#### **end\_address**

Specifies a hexadecimal number that represents a legal address at which to end the display. The default is the current address plus 127 bytes.

#### **iterations**

Specifies how many times the data is read. The default is 1.

#### **silent**

Specifies whether or not the data is displayed. Setting this field to 1 causes the data to be read but not displayed. The default is 0 (data is displayed).

### Description

The **pl** command displays the specified memory in longword format. If no address is specified, then the current memory longword and the following 31 longwords are displayed. The field displayed after the longword represents the translation of the memory contents in ASCII characters. If the memory contents can be translated to an ASCII character, then that character is displayed; otherwise, a dot is displayed.

The **silent** and **iterations** fields are often used together to continuously perform read operations, thus, avoiding slowdowns caused by displaying the data. The repeating cycles can be monitored with test equipment.

## User Commands

pl

### Example

This example displays memory longwords.

```
EB64> pl 0
00000000: E7E01021 00000000 00000000 00000000 !.....
00000010: 00000000 00000000 00000000 00000000 .....
00000020: E7E01095 00000000 00000000 00000000 .....
00000030: 00000000 00000000 00000000 00000000 .....
00000040: 00000000 00000000 00000000 00000000 .....
00000050: 00000000 00000000 00000000 00000000 .....
00000060: 00000000 00000000 00000000 00000000 .....
00000070: 00000000 00000000 00000000 00000000 .....
EB64> pl
00000090: 00000000 00000000 00000000 00000000 .....
000000A0: 00000000 00000000 00000000 00000000 .....
000000B0: 00000000 00000000 00000000 00000000 .....
000000C0: 00000000 00000000 00000000 00000000 .....
000000D0: 00000000 00000000 00000000 00000000 .....
000000E0: 74420082 644200A9 74210081 64210024 ..Bt..Bd..!t$.!d
000000F0: 48405682 F0400013 E4400003 77DE009E .V@H..@...@...w
00000100: 67DE009F 44205401 47E09402 744200A9 ...g.T D...G..Bt
EB64> pl 10000
00100000: C1000003 00000000 0010D910 00000000 .....
00100010: 2F880007 A49E0000 43C11405 40A11406 .../.....C...@
00100020: 48807722 40C20406 B4DC82F0 B49C82F8 "w.H...@.....
00100030: B4BC8300 43C5153E B7FE0020 B3FC8308 ....>..C .....
00100040: D0000007 47E20404 D0001019 00000080 .....G.....
00100050: 47FF041F 00000000 00000000 00000000 ...G.....
00100060: 43C6153E B41E0028 D0000136 A49C8018 >..C(...6.....
00100070: 43E03405 D0000309 A49C8020 43E05405 .4.C.... ..T.C
EB64> pl 10000 10000
00100000: C1000003 00000000 0010D910 00000000.....
```

## pq

The **pq** command displays the specified memory quadword (64-bit).

### Format

```
pq [start_address [end_address [iterations [silent]]]]
```

### Parameters

#### **start\_address**

Specifies a hexadecimal number that represents a legal address at which to start the display. The default is the current address.

#### **end\_address**

Specifies a hexadecimal number that represents a legal address at which to end the display. The default is the current address plus 127 bytes.

#### **iterations**

Specifies how many times the data is read. The default is 1.

#### **silent**

Specifies whether or not the data is displayed. Setting this field to 1 causes the data to be read but not displayed. The default is 0 (data is displayed).

### Description

The **pq** command displays the specified memory in quadword format. If no address is specified, then the current memory quadword and the following 15 quadwords are displayed. The field displayed after the quadword represents the translation of the memory contents in ASCII characters. If the memory contents can be translated to an ASCII character, then that character is displayed; otherwise, a dot is displayed.

The **silent** and **iterations** fields are often used together to continuously perform read operations, thus, avoiding slowdowns caused by displaying the data. The repeating cycles can be monitored with test equipment.

## User Commands

pq

### Example

This example displays memory quadwords.

```
EB64> pq
00000000: 00000000E7E01021 0000000000000000 !.....
00000010: 0000000000000000 0000000000000000 .....
00000020: 00000000E7E01095 0000000000000000 .....
00000030: 0000000000000000 0000000000000000 .....
00000040: 0000000000000000 0000000000000000 .....
00000050: 0000000000000000 0000000000000000 .....
00000060: 0000000000000000 0000000000000000 .....
00000070: 0000000000000000 0000000000000000 .....
EB64> pq 100000
00100000: 00000000C1000003 000000000010D910 .....
00100010: A49E00002F880007 40A1140643C11405 .../.....C...@
00100020: 40C2040648807722 B49C82F8B4DC82F0 "w.H...@.....
00100030: 43C5153EB4BC8300 B3FC8308B7FE0020 ...>..C .....
00100040: 47E20404D0000007 00000080D0001019 .....G.....
00100050: 0000000047FF041F 0000000000000000 ...G.....
00100060: B41E002843C6153E A49C8018D0000136 >..C(...6.....
00100070: D000030943E03405 43E05405A49C8020 .4.C.... ....T.C
```

## prb

The **prb** command reads a byte (8 bits) from the specified address in the PCI configuration space.

### Format

```
prb pci_address id bus function
```

### Parameters

#### **pci\_address**

Specifies the address in PCI space.

#### **id**

Specifies a decimal number that represents the slot assigned to the PCI device.

#### **bus**

Specifies which bus to read from. The default value is 0.

#### **function**

Specifies which function to read from. The default value is 0.

### Description

The **prb** command reads a byte from the specified address in the PCI configuration space for a device specified by the **id**. If the motherboard does not support PCI, then this command is not implemented. If your system configuration supports multiple PCI buses, use the parameters to specify the PCI device. Use the **pcishow** command to view the available PCI devices.

### Example

```
EB66> prb 0 19  
86
```

## User Commands

### preg

### preg

The **preg** command displays the saved CPU general-purpose register state.

### Format

**preg** [address]

### Parameters

#### address

Specifies an alternate address for the saved-state area.

### Description

The **preg** command displays the contents of the CPU general-purpose registers stored in the saved-state area. A register state is stored when a breakpoint is encountered or the PALcode reset flow is entered.

### Example

```
EB64> preg
General Purpose Registers
register file @: 0000C040
r00: 0000000000000020 0000000000000005 000000000000C000 000000000000000D
r04: 000000000000003F8 0000000000000000 0000000000000000 000000000000000D
r08: FFFFFFFC000005F470 0000000000027340 0444306453605341 0A110C485F6EA26E
r12: 208090EA6024C19C 882C08AA92065B2D 4100610AE100244F 9E2891ACA8A9D984
r16: 0000000000100000 000000000000000D 0000000000000006 0000000000000030
r20: 0000000E20026335 5619A46B2B1A5125 0000000000000000 000000000000000D
r24: 0000000000000003 0000000000000000 FFFFFFFC0000042C3C 0000000000100000
r28: FFFFFFFC02C0000000 FFFFFFFC000006C1E0 0000000000FFDF40 0000000000000003
PC: 000000000000000D PS: 000000000000000D
```



## prl

The **prl** command reads a longword (32 bits) from the specified address in the PCI configuration space.

### Format

```
prl pci_address id bus function
```

### Parameters

#### **pci\_address**

Specifies the address in PCI space.

#### **id**

Specifies a decimal number that represents the slot assigned to the PCI device.

#### **bus**

Specifies which bus to read from. The default value is 0.

#### **function**

Specifies which function to read from. The default value is 0.

### Description

The **prl** command reads a longword from the specified address in the PCI configuration space for a device specified by the **id**. If the motherboard does not support PCI, then this command is not implemented. If your system configuration supports multiple PCI buses, use the parameters to specify the PCI device. Use the **pcishow** command to view the available PCI devices.

### Example

```
EB66> prl 0 19  
04848086
```

## User Commands

### **prw**

### **prw**

The **prw** command reads a word (16 bits) from the specified address in the PCI configuration space.

### **Format**

```
prw pci_address id bus function
```

### **Parameters**

#### **pci\_address**

Specifies the address in PCI space.

#### **id**

Specifies a decimal number that represents the slot assigned to the PCI device.

#### **bus**

Specifies which bus to read from. The default value is 0.

#### **function**

Specifies which function to read from. The default value is 0.

### **Description**

The **prw** command reads a word from the specified address in the PCI configuration space for a device specified by the **id**. If the motherboard does not support PCI, then this command is not implemented. If your system configuration supports multiple PCI buses, use the parameters to specify the PCI device. Use the **pcishow** command to view the available PCI devices.

## Example

```
AlphaPC 64> pcishow

PCI Address Mapping windows are:
  (1) PCI Base = 0x00100000, Size = 0x00100000
      Translated Base = 0x00100000

Bus = 0
  primary = 0, secondary = 0, subordinate = 1
  PCI I/O space = 1000, PCI Mem space = 100000
  PCI I/O base = B000, PCI Mem base = 200000
PCI slot 17, vendor = 0x1011, device = 0x1
  PCI IO Base = 0x0, PCI IO Size = 0x0
  PCI Mem Base = 0x0, PCI Mem Size = 0x0
  PCI-PCI bridge
PCI slot 19, vendor = 0x8086, device = 0x484
  PCI IO Base = 0x0, PCI IO Size = 0x0
  PCI Mem Base = 0x0, PCI Mem Size = 0x0
  Non-VGA compatible device

Bus = 1
  primary = 0, secondary = 1, subordinate = 1
  PCI I/O space = 1000, PCI Mem space = 100000
  PCI I/O base = B000, PCI Mem base = 200000
PCI slot 6, vendor = 0x1011, device = 0x2
  PCI IO Base = 0xB000, PCI IO Size = 0x80
  PCI Mem Base = 0x200000, PCI Mem Size = 0x80
  Ethernet controller

AlphaPC 64> prw 0 6 1
1011
AlphaPC 64> prw 0 19
8086
```

## User Commands

### pw

### pw

The **pw** command displays the specified memory word (16-bit).

### Format

**pw** [start\_address [end\_address [iterations [silent]]]]

### Parameters

#### **start\_address**

Specifies a hexadecimal number that represents a legal address at which to start the display. The default is the current address.

#### **end\_address**

Specifies a hexadecimal number that represents a legal address at which to end the display. The default is the current address plus 127 bytes.

#### **iterations**

Specifies how many times the data is read. The default is 1.

#### **silent**

Specifies whether or not the data is displayed. Setting this field to 1 causes the data to be read but not displayed. The default is 0 (data is displayed).

### Description

The **pw** command displays the specified memory in word format. If no address is specified, then the current memory word and the following 63 words are displayed. The field displayed after the word represents the translation of the memory contents in ASCII characters. If the memory contents can be translated to an ASCII character, then that character is displayed; otherwise, a dot is displayed.

The **silent** and **iterations** fields are often used together to continuously perform read operations, thus, avoiding slowdowns caused by displaying the data. The repeating cycles can be monitored with test equipment.

## Example

This example displays eight memory addresses starting with 100000<sub>16</sub> in word format.

```
EB64> pw 100000
00100000: 0003 C100 0000 0000 D910 0010 0000 0000 .....
00100010: 0007 2F88 0000 A49E 1405 43C1 1406 40A1 .../.....C...@
00100020: 7722 4880 0406 40C2 82F0 B4DC 82F8 B49C "w.H...@.....
00100030: 8300 B4BC 153E 43C5 0020 B7FE 8308 B3FC ....>..C .....
00100040: 0007 D000 0404 47E2 1019 D000 0080 0000 .....G.....
00100050: 041F 47FF 0000 0000 0000 0000 0000 0000 ...G.....
00100060: 153E 43C6 0028 B41E 0136 D000 8018 A49C >..C(...6.....
00100070: 3405 43E0 0309 D000 8020 A49C 5405 43E0 .4.C.... ....T.C
```

## User Commands

### pwb

### pwb

The **pwb** command writes a byte (8 bits) to an address in the PCI configuration space.

### Format

```
pwb pci_address id data bus function
```

### Parameters

#### **pci\_address**

Specifies which address to write to.

#### **id**

Specifies a decimal number that represents the slot assigned to the PCI device.

#### **data**

Specifies the value that is written to the **pci\_address**.

#### **bus**

Specifies which bus to write to. The default value is 0.

#### **function**

Specifies which function to write from. The default value is 0.

### Description

The **pwb** command writes a byte to the specified address in the PCI configuration space for a device specified by the **id**. If the motherboard does not support PCI, then this command is not implemented. If your system configuration supports multiple PCI buses, use the parameters to specify the PCI device. Use the **pcishow** command to view the available PCI devices.

### Example

```
EB66> prb 4f 19  
3F  
EB66> pwb 4f 19 2f  
EB66> prb 4f 19  
2F
```

## pwl

The **pwl** command writes a longword (32 bits) to an address in the PCI configuration space.

### Format

```
pwl pci_address id data bus function
```

### Parameters

#### **pci\_address**

Specifies which address to write to.

#### **id**

Specifies a decimal number that represents the slot assigned to the PCI device.

#### **data**

Specifies the value that is written to the pci\_address.

#### **bus**

Specifies which bus to write to. The default value is 0.

#### **function**

Specifies which function to write from. The default value is 0.

### Description

The **pwl** command writes a longword to the specified address in the PCI configuration space for a device specified by the id. If the motherboard does not support PCI, then this command is not implemented. If your system configuration supports multiple PCI buses, use the parameters to specify the PCI device. Use the **pcishow** command to view the available PCI devices.

### Example

```
EB66> pwl 4f 19 0000a6f3
```

## User Commands

### **pww**

### **pww**

The **pww** command writes a word (16 bits) to an address in the PCI configuration space.

### **Format**

**pww** pci\_address id data bus function

### **Parameters**

#### **pci\_address**

Specifies which address to write to.

#### **id**

Specifies a decimal number that represents the slot assigned to the PCI device.

#### **data**

Specifies the value that is written to the pci\_address.

#### **bus**

Specifies which bus to write to. The default value is 0.

#### **function**

Specifies which function to write from. The default value is 0.

### **Description**

The **pww** command writes a word to the specified address in the PCI configuration space for a device specified by the id. If the motherboard does not support PCI, then this command is not implemented. If your system configuration supports multiple PCI buses, use the parameters to specify the PCI device. Use the **pcishow** command to view the available PCI devices.

### **Example**

```
EB66> pww 4f 19 4
EB66> prw 4f 19
0004
```



## **rabox**

The **rabox** command reads the CPU ABOX\_CTL register.

### **Format**

**rabox**

### **Parameters**

None.

### **Description**

The **rabox** command reads the CPU ABOX\_CTL register and displays the value in hexadecimal format.

This command applies only to motherboard designs based on the Alpha 21064 and Alpha 21066 microprocessors.

### **Example**

```
EB64> rabox  
00000000000000428
```

## User Commands

**rb**

**rb**

The **rb** command reads a byte (8 bits) from a register port in I/O address space.

### Format

**rb** register [iterations [silent]]

### Parameters

#### **register**

Specifies the register from the I/O address space.

#### **iterations**

Specifies how many times the data is read. The default is 1.

#### **silent**

Specifies whether or not the data is displayed. Setting this field to 1 causes the data to be read but not displayed. The default is 0 (data is displayed).

### Description

The **rb** command reads a byte from the specified register in I/O address space.

### Example

```
EB64> rb 370  
04
```

## rbcfg

The **rbcfg** command reads the backup cache configuration register.

### Format

**rbcfg**

### Parameters

None.

### Description

The **rbcfg** command reads a shadow copy of the backup cache configuration register.

If you manually change this register by writing to its architected address, the change will *not* be reflected for this command. You must use the **wbctl** or **wbcfg** command to make any changes.

This command is implemented only for the Alpha 21164 microprocessor family.

### Example

```
EB164> rbcfg  
0000000001E22772
```

## User Commands

### rbctl

### rbctl

The **rbctl** command reads the backup cache control register.

### Format

**rbctl**

### Parameters

None.

### Description

The **rbctl** command reads a shadow copy of the backup cache control register.

If you manually change this register by writing to its architected address, the change will *not* be reflected for this command. You must use the **wbctl** or **wbcfg** command to make any changes.

This command is implemented only for the Alpha 21164 microprocessor family.

### Example

```
EB164> rbctl  
0000000000028051
```

## rbiu

The **rbiu** command reads the CPU BIU\_CTL register.

### Format

**rbiu**

### Parameters

None.

### Description

The **rbiu** command reads the CPU BIU\_CTL register and displays the value in hexadecimal format.

This command applies only to motherboard designs based on the Alpha 21064 microprocessor.

### Example

```
EB64> rbiu  
0000000E2001C645
```

## User Commands

### riccsr

#### riccsr

The **riccsr** command reads the CPU ICCSR register.

#### Format

**riccsr**

#### Parameters

None.

#### Description

The **riccsr** command reads the CPU ICCSR register and displays the value in the CPU write format. For more information about the write format, see the hardware reference manual that corresponds to your CPU chip.

#### Example

```
EB64> riccsr  
000006F800000000
```

**rl**

The **rl** command reads a longword (32 bits) from a register port in I/O address space.

**Format**

```
rl register [iterations [silent]]
```

**Parameters****register**

Specifies the register from the I/O address space.

**iterations**

Specifies how many times the data is read. The default is 1.

**silent**

Specifies whether or not the data is displayed. Setting this field to 1 causes the data to be read but not displayed. The default is 0 (data is displayed).

**Description**

The **rl** command reads a longword from the specified register in I/O address space.

**Example**

```
EB64> rl 370  
0000A6F3
```

## User Commands

### **rmode**

### **rmode**

The **rmode** command sets the **dis** command register display mode.

### **Format**

**rmode** [mode]

### **Parameters**

#### **mode**

Determines the mode. If set (1), the software register names are displayed. If cleared (0), the hardware register names are displayed. The default is 0.

### **Description**

The **rmode** command specifies whether hardware register names, such as r16, or software register names, such as a0, are displayed with the **dis** command.



The following table displays the DIGITAL UNIX Alpha microprocessor register usage.

Hardware Register Name	Software Register Name	Use and Linkage
r0	v0	Used for expression evaluation and to hold integer function results.
r1...r8	t0...t7	Temporary registers; not preserved across procedure calls.
r9...r14	s0...s5	Saved registers; their values must be preserved across procedure calls.
r15	FP or s6	Frame pointer or a saved register.
r16...r21	a0...a5	Argument registers; used to pass the first six integer type arguments; their values are not preserved across procedure calls.
r22...r25	t8...t11	Temporary registers; not preserved across procedure calls.
r26	ra	Contains the return address; used for expression evaluation.
r27	pv or t12	Procedure value or a temporary register.
r28	at	Assembler temporary register; not preserved across procedure calls.
r29	GP	Global pointer.
r30	SP	Stack pointer.
r31	zero	Always has the value 0.

If you enter the command without a parameter, then the current mode is displayed. The **rmode** setting is stored in battery-backed RAM.

## User Commands

### rmode

### Example

```
EB64> rmode
rmode = 0
EB64> dis 243a0
000243A0: 43020122      subl   r24, r2, r2
000243A4: 48441722      sll    r2, 0x20, r2
000243A8: 74420050      mt     r2, cc
000243AC: 64630082      mf     r3, pt2
000243B0: 209F07E1      lda   r4, 2017(zero)
000243B4: 48855724      sll   r4, 0x2A, r4
000243B8: 44640103      bic   r3, r4, r3
000243BC: 47203019      and   r25, 0x1, r25
EB64> dis
000243C0: 4B037698      srl   r24, 0x1B, r24
000243C4: 4703F118      bic   r24, 0x1F, r24
000243C8: 47190418      bis   r24, r25, r24
000243CC: 4B055738      sll   r24, 0x2A, r24
000243D0: 44780403      bis   r3, r24, r3
000243D4: 746300A2      mt     r3, A2
000243D8: 77FF0055      mt     zero, flushIc
000243DC: 77FF0000      mt     zero, 0
EB64> rmode 1
EB64> dis 243a0
000243A0: 43020122      subl   t10, t1, t1
000243A4: 48441722      sll   t1, 0x20, t1
000243A8: 74420050      mt     t1, cc
000243AC: 64630082      mf     t2, pt2
000243B0: 209F07E1      lda   t3, 2017(zero)
000243B4: 48855724      sll   t3, 0x2A, t3
000243B8: 44640103      bic   t2, t3, t2
000243BC: 47203019      and   t11, 0x1, t11
EB64> dis
000243C0: 4B037698      srl   t10, 0x1B, t10
000243C4: 4703F118      bic   t10, 0x1F, t10
000243C8: 47190418      bis   t10, t11, t10
000243CC: 4B055738      sll   t10, 0x2A, t10
000243D0: 44780403      bis   t2, t10, t2
000243D4: 746300A2      mt     t2, A2
000243D8: 77FF0055      mt     zero, flushIc
000243DC: 77FF0000      mt     zero, 0
EB64>
```

## romboot

The **romboot** command loads the specified image from ROM and begins execution.

### Format

**romboot** [type] [address]

### Parameters

#### type

Specifies the image to load into ROM. If the type is specified as #0, then any header information is ignored and the entire contents of the ROM is loaded. The default is to load and execute the first image in the system ROM.

#### address

Specifies the starting address for loading the image into ROM.

### Description

The **romboot** command loads and executes the operating system and associated firmware from the system ROM. Use the **romlist** command to display the images contained in the ROM. You can specify the type as a number or a name.

Type_number	Type_name	Description
0	DBM	Alpha Motherboard Debug Monitor
1	NT	Windows NT
2	VMS	OpenVMS
3	UNIX	DIGITAL UNIX
7	LINUX	Linux, MILO
8	VXWORKS	VxWorks
10	SROM	Serial ROM

## User Commands

### romboot

The **romboot** command can also be used to select a ROM image based on its position in the ROM. Specifying the type as #0 selects the entire ROM. Specifying the type as #1 selects the first image; #2 selects the second image, and so on.

You can specify an address to override what is in the image file header. You may also use the **bootadr** command. Use the system reset to reset the motherboard to the initial booted state.

### Example

```
AlphaPC 64> romboot
Searching for ROM image #1
  Header Size..... 52 bytes
  Image Checksum..... 0x581A (22554)
  Image Size (Uncomp). 117160 (114 KB)
  Compression Type.... 0
  Image Destination... 0x0000000000300000
  Header Version..... 1
  Firmware ID..... 0 - Alpha Evaluation Board Debug Monitor
  ROM Image Size..... 117160 (114 KB)
  Firmware ID (Opt).. 0000000000000000  ASCII: .....
  Header Checksum..... 0x8F5C
Loading ROM to address 00300000
Image checksum verified. 0x581A
Loaded 117160 bytes starting at 300000 to 31C9A8
Jumping to 0x300000...
AlphaPC 64> romboot #2
Searching for ROM image #2
  Header Size..... 52 bytes
  Image Checksum..... 0xD38C (54156)
  Image Size (Uncomp). 211728 (206 KB)
  Compression Type.... 0
  Image Destination... 0x0000000000300000
  Header Version..... 1
  Firmware ID..... 1 - Windows NT Firmware
  ROM Image Size..... 211728 (206 KB)
  Firmware ID (Opt).. 0305109502131030  ASCII: 0.....
  Header Checksum..... 0xCED2
Loading ROM to address 00300000
Image checksum verified. 0xD38C
Loaded 211728 bytes starting at 300000 to 333B10
Jumping to 0x300000...
AlphaPC 64> romboot unix
Searching for the "Alpha SRM Console".
The specified ROM image was not found
```

## User Commands

### romboot

```
AlphaPC 64> romboot nt
Searching for the "Windows NT Firmware".
  Header Size..... 52 bytes
  Image Checksum..... 0xD38C (54156)
  Image Size (Uncomp). 211728 (206 KB)
  Compression Type.... 0
  Image Destination... 0x0000000000300000
  Header Version..... 1
  Firmware ID..... 1 - Windows NT Firmware
  ROM Image Size..... 211728 (206 KB)
  Firmware ID (Opt).. 0305109502131030 ASCII: 0.....
  Header Checksum..... 0xCED2
Loading ROM to address 00300000
Image checksum verified. 0xD38C
Loaded 211728 bytes starting at 300000 to 333B10
Jumping to 0x300000...
```

## User Commands

### romlist

### romlist

The **romlist** command lists the ROM image headers contained in ROM.

### Format

#### romlist

### Parameters

None.

### Description

The **romlist** command searches the system ROM for any ROM image headers that might be present. It then prints a summary for each header found.

### Example

```
AlphaPC 64> romlist

ROM image header found at offset: 0x000000
Header Size..... 52 bytes
Image Checksum..... 0x8111
Image Size (Uncomp). 129552 (126 KB)
Compression Type.... 0
Image Destination... 0x0000000000300000
Header Version..... 1
Firmware ID..... 0 - Alpha Evaluation Board Debug Monitor
ROM Image Size..... 129552 (126 KB)
Firmware ID (Opt.).. 0000000000000000 ASCII: .....
Header Checksum..... 0xA839

ROM image header found at offset: 0x040000
Header Size..... 52 bytes
Image Checksum..... 0xD38C
Image Size (Uncomp). 211728 (206 KB)
Compression Type.... 0
Image Destination... 0x0000000000300000
Header Version..... 1
Firmware ID..... 1 - Windows NT Firmware
ROM Image Size..... 211728 (206 KB)
Firmware ID (Opt.).. 0305109502131030 ASCII: 0.....
Header Checksum..... 0xCED25

AlphaPC 64>
```

## romload

The **romload** command loads the specified image from ROM to the specified address.

### Format

**romload** [type] [address]

### Parameters

#### type

Specifies the image to load into ROM. If the type is specified as #0, then any header information is ignored and the entire contents of the ROM is loaded. The default is to load the first image in the system ROM.

#### address

Specifies the starting address for loading the image into ROM.

### Description

The **romload** command loads the operating system and associated firmware from the system ROM. Use the **romlist** command to display the images contained in the ROM. You can specify the type as a number or a name.

Type_number	Type_name	Description
0	DBM	Alpha Motherboard Debug Monitor
1	NT	Windows NT
2	VMS	OpenVMS
3	UNIX	DIGITAL UNIX
7	LINUX	Linux, MILO
8	VXWORKS	VxWorks
10	SROM	Serial ROM

## User Commands

### romload

The **romload** command can also be used to select a ROM image based on its position in the ROM. Specifying the type as #0 selects the entire ROM. Specifying the type as #1 selects the first image; #2 selects the second image, and so on.

You can specify an address to override what is in the image file header. You may also use the **bootadr** command. Use the **jtopal** command to execute the image.

### Example

```
AlphaPC 64> romload #0
Loading entire ROM.
Loading ROM to address 00200000
Loaded 1048576 bytes from 200000 to 300000
AlphaPC 64>
AlphaPC 64> romload #1
Searching for ROM image #1
  Header Size..... 52 bytes
  Image Checksum..... 0x581A (22554)
  Image Size (Uncomp).. 117160 (114 KB)
  Compression Type.... 0
  Image Destination... 0x0000000000300000
  Header Version..... 1
  Firmware ID.....0 - Alpha Evaluation Board Debug Monitor
  ROM Image Size..... 117160 (114 KB)
  Firmware ID (Opt.).. 0000000000000000 ASCII: .....
  Header Checksum..... 0x8F5C
Loading ROM to address 00300000
Image checksum verified. 0x581A
Loaded 117160 bytes from 300000 to 31C9A8
AlphaPC 64>
AlphaPC 64> romload
Searching for ROM image #1
  Header Size..... 52 bytes
  Image Checksum..... 0x581A (22554)
  Image Size (Uncomp).. 117160 (114 KB)
  Compression Type.... 0
  Image Destination... 0x0000000000300000
  Header Version..... 1
  Firmware ID.....0 - Alpha Evaluation Board Debug Monitor
  ROM Image Size..... 117160 (114 KB)
  Firmware ID (Opt.).. 0000000000000000 ASCII: .....
  Header Checksum..... 0x8F5C
Loading ROM to address 00300000
Image checksum verified. 0x581A
Loaded 117160 bytes from 300000 to 31C9A8
AlphaPC 64>
AlphaPC 64> romload unix
Searching for "Alpha SRM Console".
The specified ROM image was not found
AlphaPC 64>
```



## User Commands

### romload

```
AlphaPC 64> romload nt
Searching for "Windows NT Firmware".
  Header Size..... 52 bytes
  Image Checksum..... 0xD38C (54156)
  Image Size (Uncomp). 211728 (206 KB)
  Compression Type.... 0
  Image Destination... 0x0000000000300000
  Header Version..... 1
  Firmware ID..... 1 - Windows NT Firmware
  ROM Image Size..... 211728 (206 KB)
  Firmware ID (Opt).. 0305109502131030 ASCII: 0.....
  Header Checksum.... 0xCED2
Loading ROM to address 00300000
Image checksum verified. 0xD38C
Loaded 211728 bytes from 300000 to 333B10
AlphaPC 64>
```

## User Commands

### romverify

#### romverify

The **romverify** command compares an image in memory to an image in the ROM.

#### Format

**romverify** [type [address]]

#### Parameters

##### type

Specifies the name or number of an image in the ROM to compare against memory. If the type specified is #0, then any header information is ignored and the entire contents of the ROM are compared. If the type is #*n* the *n*th image in the ROM will be used (#2 is the second entry). The default is to compare the first image in the system ROM.

##### address

Specifies the starting address for comparing the image in the ROM. The bootadr is the default.

#### Description

The **romverify** command compares an image in memory to an image in the ROM. Use the **romlist** command to display the images contained in the ROM. You can specify the type as a number or a name.

Type_number	Type_name	Description
0	DBM	Alpha Motherboard Debug Monitor
1	NT	Windows NT
2	VMS	OpenVMS
3	UNIX	DIGITAL UNIX
7	LINUX	Linux, MILO
8	VXWORKS	VxWorks
10	SROM	Serial ROM

## Examples

```
AlphaPC164> romload #0 300000
Loading entire ROM.
Loading ROM to address 00300000
Loaded 1048576 bytes starting at 0x300000 to 0x3ffffff
AlphaPC164> romverify #0
Comparing entire ROM to image at 0x300000.
Images match.
AlphaPC164> netload PC164dbm.rom
Attempting BOOTP...
Loading PC164dbm.rom at 0x300000
My IP address:      192.168.0.107
Server IP address: 192.168.0.114
#####
File loaded successfully.  Size = 0x28380 (164736)
AlphaPC164> romverify dbm
Searching for the "Alpha Evaluation Board Debug Monitor".
Comparing to image at 0x300000.
Images match.
AlphaPC164> romverify 0 300000
Searching for the "Alpha Evaluation Board Debug Monitor".
Comparing to image at 0x300000.
Images match.
AlphaPC164> romverify #1 300000
Searching for ROM image #1
Comparing to image at 0x300000.
Images do not match.
AlphaPC164> romverify #2 300000
Searching for ROM image #2
Comparing to image at 0x300000.
Images match.
```

## User Commands

### rsys

### rsys

The **rsys** command reads the EB64 system control register.

### Format

**rsys**

### Parameters

None.

### Description

The **rsys** command displays the current value of the system register. This command applies only to the EB64.

### Example

```
EB64> rsys  
840000
```

## rw

The **rw** command reads a word (16 bits) from a register port in I/O address space.

### Format

```
rw register [iterations [silent]]
```

### Parameters

#### register

Specifies the register from the I/O address space.

#### iterations

Specifies how many times the data is read. The default is 1.

#### silent

Specifies whether or not the data is displayed. Setting this field to 1 causes the data to be read but not displayed. The default is 0 (data is displayed).

### Description

The **rw** command reads a word from the specified register in I/O address space.

### Example

```
EB64> rw 372  
0000  
EB64> rw 370  
A6B3
```

## User Commands

**sb**

**sb**

The **sb** command searches memory by bytes (8-bit).

### Format

**sb** start\_address end\_address string [inverse]

### Parameters

#### **start\_address**

Specifies the address at which to begin the search.

#### **end\_address**

Specifies the address at which to end the search.

#### **string**

Specifies the search string.

#### **inverse**

Specifies whether to search for a matching string (0) or a nonmatching string (1).  
The default is 0 (search for a matching string).

### Description

The **sb** command searches memory by byte chunks for the specified string. You can use an asterisk (\*) as a wildcard character for single-character matching.

## Example

```
EB64> p1 10000 10080
00100000: C3E00007 00000000 00000000 00000000 .....
00100010: 00000000 00000000 00000000 00000000 .....
00100020: 221F0000 26100012 6BF00000 00000000 ..."...&...k...
00100030: 00000000 00000000 00000000 00000000 .....
00100040: 00000000 00000000 00000000 00000000 .....
00100050: 00000000 00000000 00000000 00000000 .....
00100060: 00000000 00000000 00000000 00000000 .....
00100070: 00000000 00000000 00000000 00000000 .....
00100080: 00000000 00000000 00000000 00000000.....
EB64> sb 10000 10080 2*
val = 20 mask = F0
occurrence at 00100023 22
occurrence at 00100027 26
EB64> sb 10000 10080 1*
val = 10 mask = F0
occurrence at 00100022 1F
occurrence at 00100024 12
occurrence at 00100026 10
EB64> sb 10000 10080 1f
val = 1F mask = FF
occurrence at 00100022 1F
```

## User Commands

### setbaud

#### setbaud

The **setbaud** command sets the baud rate for the specified communication port connection.

#### Format

**setbaud** port baud\_rate

#### Parameters

##### port

Specifies the number identifier for the keyboard or serial port.

##### baud\_rate

Specifies the baud rate for the specified port. The default is 9600.

#### Description

The **setbaud** command sets the baud rate for the specified keyboard or serial communication port. The baud rate can be set to 1200, 2400, 9600, 19200, or 38400.

The following table shows the port identifier numbers.

Port ID	Port Name
0	Keyboard port
1	Serial communication port 1
2	Serial communication port 2

#### Example

```
EB64> setbaud 1 2400
```



## setty

The **setty** command sets the Debug Monitor to the specified port.

### Format

**setty** port

### Parameters

**port**

Specifies the number identifier for the keyboard or serial port.

### Description

The **setty** command specifies the port used for Debug Monitor interaction. The following table shows the port identifier numbers.

Port ID	Port Name
0	Keyboard port
1	Serial communication port 1
2	Serial communication port 2

### Example

```
EB64> setty 1
```

## User Commands

### sl

### sl

The **sl** command searches memory by longwords (32-bit).

### Format

**sl** start\_address end\_address string [inverse]

### Parameters

#### **start\_address**

Specifies the address at which to begin the search.

#### **end\_address**

Specifies the address at which to end the search.

#### **string**

Specifies the search string.

#### **inverse**

Specifies whether to search for a matching string (0) or a nonmatching string (1).  
The default is 0 (search for a matching string).

### Description

The **sl** command searches memory by longword chunks for the specified string. You can use an asterisk (\*) as a wildcard character for single-character matching.

## Example

```
EB64> pl 100000
00100000: C3E00007 00000000 00000000 00000000 .....
00100010: 00000000 00000000 00000000 00000000 .....
00100020: 221F0000 26100012 6BF00000 00000000 ..."...&...k....
00100030: 00000000 00000000 00000000 00000000 .....
00100040: 00000000 00000000 00000000 00000000 .....
00100050: 00000000 00000000 00000000 00000000 .....
00100060: 00000000 00000000 00000000 00000000 .....
00100070: 00000000 00000000 00000000 00000000 .....
EB64> sl 100000 100070 2*****
val = 20000000 mask = F0000000
occurrence at 00100020 221F0000
occurrence at 00100024 26100012
EB64> sl 100000 100070 2*1*****
val = 20100000 mask = F0F00000
occurrence at 00100020 221F0000
occurrence at 00100024 26100012
```

## User Commands

### sq

### sq

The **sq** command searches memory by quadwords (64-bit).

### Format

```
sq start_address end_address string [inverse]
```

### Parameters

#### **start\_address**

Specifies the address at which to begin the search.

#### **end\_address**

Specifies the address at which to end the search.

#### **string**

Specifies the search string.

#### **inverse**

Specifies whether to search for a matching string (0) or a nonmatching string (1). The default is 0 (search for a matching string).

### Description

The **sq** command searches memory by quadword chunks for the specified string. You can use an asterisk (\*) as a wildcard character for single-character matching.

## Example

```
EB64> pq
00000000: 00000000C3E00007 0000000000000000 .....
00000010: 0000000000000000 0000000000000000 .....
00000020: 26100002221F0000 000000006BF00000 ..."...&...k...
00000030: 0000000000000000 0000000000000000 .....
00000040: 0000000000000000 0000000000000000 .....
00000050: 0000000000000000 0000000000000000 .....
00000060: 0000000000000000 0000000000000000 .....
00000070: 0000000000000000 0000000000000000 .....
EB64> sq 100000 100080 2
val = 2 mask = FFFFFFFFFFFFFFFF
value not found
EB64> sq 100000 100080 26100002221F0000
value = 26100002221F0000 mask = FFFFFFFFFFFFFFFF
occurrence at 00000020 26100002221F0000
```

## User Commands

### step

### step

The **step** command executes the next instruction.

### Format

**s[tep]**

### Parameters

None.

### Description

Use the **step** command and the **next** command to execute a machine instruction. When the instruction contains a subroutine call, the **step** command steps into the subroutine being called and the **next** command executes that subroutine.

In the following example, the **step** command used at address 00200034 steps to the first instruction of the subroutine being called at address 002000c0. The **next** command used at address 002000ec executes the subroutine being called and steps to the next instruction at address 002000f0.

## Example

```
EB164> dis
00200030: a77d8010          ldq   r27, 32784(r29)
00200034: 6b5b4000          jsr   r26, r27
00200038: 27ba0001          ldah  r29, 1(r26)
0020003c: 23bdc148          lda   r29, 49480(r29)
EB164> step
00200030: a77d8010          ldq   r27, 32784(r29)
EB164> step
00200034: 6b5b4000          jsr   r26, r27
EB164> step
002000c0: 27bb0001          ldah  r29, 1(r27)
.
.
.
EB164> dis
002000e8: a77d8040          ldq   r27, 32832(r29)
002000ec: 6b5b46b8          jsr   r26, r27
002000f0: 27ba0001          ldah  r29, 1(r26)
EB164> step
002000e8: a77d8040          ldq   r27, 32832(r29)
EB164> step
02000ec: 6b5b46b8          jsr   r26, r27
EB164> next
002000f0: 27ba0001          ldah  r29, 1(r26)
EB164>
```

## User Commands

### stop

### stop

The **stop** command sets a breakpoint.

### Format

**stop** address

### Parameters

#### address

Specifies the address at which the breakpoint is set.

### Description

The **stop** command sets a breakpoint at the specified address. When a breakpoint is encountered, all current register values are stored in memory and can be viewed with the **preg** and **pfreg** commands.

### Example

```
EB64> stop 100000
EB64> go
Executing at 0x100000...
00100000: C1000003          br    r8, 100010
EB64> stop 100200
EB64> go
Executing at 0x100000...
00100200: 4A671793          sra   r19, 0x38, r19
EB64> cont
00100200: 4A671793          sra   r19, 0x38, r19
This simple program prints the size of
various data types in bytes.
    char   = 1
   short  = 2
    int    = 4
    long   = 8
   float  = 4
   double = 8
Alpha 21064 Evaluation Board (EB64) Debug Monitor
Version: Fri Apr 09 20:50:11 EDT 1993
Bootadr: 0x100000, memSize: 0x2000000
```



## sum

The **sum** command computes the checksum of the data in the specified range.

## Format

```
sum start_address end_address
```

## Parameters

### start\_address

Specifies the address at which the checksum check begins.

### end\_address

Specifies the address at which the checksum check ends.

## Description

The **sum** command prints the checksum of the data contained in the specified memory range. The algorithm used computes a 16-bit checksum and is compatible with the standard BSD4.3 algorithm provided in most implementations of UNIX (**sum**), thus allowing easy comparisons of images in the motherboard's memory with those on the UNIX host.

## Example

```
AlphaPC 64> netload pc64dbm.rom
Digital Semiconductor 21040 (0): Initializing
    Hardware address = BA-98-76-54-32-10
    Trying 10 Base T
    Switching to AUI
MAC address: BA-98-76-54-32-10
Attempting BOOTP...
Loading /sae_share/boot/user1/pc64/pc64dbm.rom at 0x300000
    My IP address: 16.123.45.67
    Server IP address: 16.123.45.69
#####
File loaded successfully. Size = 0x30B80 (199552)
AlphaPC 64> sum 300000 330B7F
0xe5cc 58828
```

## User Commands

### sw

### sw

The **sw** command searches memory by words (16-bit).

### Format

**sw** start\_address end\_address string [inverse]

### Parameters

#### start\_address

Specifies the address at which to begin the search.

#### end\_address

Specifies the address at which to end the search.

#### string

Specifies the search string.

#### inverse

Specifies whether to search for a matching string (0) or a nonmatching string (1).  
The default is 0 (search for a matching string).

### Description

The **sw** command searches memory by word chunks for the specified string. You can use an asterisk (\*) as a wildcard character for single-character matching.

### Example

```
EB64> p1 100000 100080
00100000: C3E00007 00000000 00000000 00000000 .....
00100010: 00000000 00000000 00000000 00000000 .....
00100020: 221F0000 26100012 6BF00000 00000000 .."...&...k....
00100030: 00000000 00000000 00000000 00000000 .....
00100040: 00000000 00000000 00000000 00000000 .....
00100050: 00000000 00000000 00000000 00000000 .....
00100060: 00000000 00000000 00000000 00000000 .....
00100070: 00000000 00000000 00000000 00000000 .....
00100080: 00000000 00000000 00000000 00000000 .....
EB64> sw 100000 100080 2*1*
val = 2010 mask = F0F0
occurrence at 00100022 221F
occurrence at 00100026 2610
```

## swpipl

The **swpipl** command sets or displays the current interrupt priority level (IPL) of the CPU.

### Format

**swpipl** [ipl]

### Parameters

**ipl**

Specifies the IPL ranging from 0 to 7 as defined for DIGITAL UNIX by the *Alpha AXP Architecture Reference Manual*.

### Description

The **swpipl** command reports the current IPL when no parameter is provided. When a value of 0 to 7 is provided to the **swpipl** command, the current IPL is set to that value. This command uses the swpipl PALcode instruction for DIGITAL UNIX defined by the *Alpha AXP Architecture Reference Manual*. The CPU arbitrates interrupt requests based on the IPL. When the current IPL is lower than a pending interrupt request, the CPU will raise the IPL while it services that interrupt. At IPL 7, no interrupt requests are handled. To avoid interrupt complexities when debugging hardware, the Debug Monitor is designed for minimal use of interrupts. Therefore, at startup, the IPL is set to 7 and can be lowered on demand using the **swpipl** command. Other commands that affect the IPL are the **mcheck** and the **ladebug** commands.

In the following example, the IPL is lowered from 6 to 4.

### Example

```
AlphaPC 164> swpipl
Current Interrupt Priority Level: 6
AlphaPC 164> swpipl 4
AlphaPC 164> swpipl
Current Interrupt Priority Level: 4
AlphaPC 164>
```

## User Commands

### sysshow

### sysshow

The **sysshow** command displays all SROM parameters.

### Format

**sysshow**

### Parameters

None.

### Description

The **sysshow** command displays the system status passed from the SROM at initialization or reset. Refer to your motherboard's user's manual for more information about the SROM parameters displayed.

### Example

```
EB66> sysshow
abox_ctl :      428
bcr0     :      64C0    bcr1     : 10064C0
bcr2     :          0    bcr3     :          0
bmr0     :  F00000    bmr1     :  F00000
bmr2     :          0    bmr3     :          0
srom_rev :      1805    proc_id  :          4
mem_size : 2000000    cycle_cnt:      1771
signature: DECB0001    proc_mask:          1
sysctx   :          0    valid    :          1
```

## tip

The **tip** command connects to the specified serial communication port.

### Format

**tip** port

### Parameters

**port**

Specifies the serial port.

### Description

The **tip** command is a subset of the DIGITAL UNIX `t i p` command. It allows you to connect directly from the motherboard to the specified serial communication port. You can specify 1 for serial port 1, or specify 2 for serial port 2.

### Example

In this example, the host system is connected to serial port 1.

```
EB64> tip 1
```

## User Commands

### version

#### version

The **version** command displays the current Debug Monitor firmware version information.

#### Format

**version**

#### Parameters

None.

#### Description

The **version** command displays the current Debug Monitor firmware version information. This information is also displayed in the banner when you power up the motherboard.

#### Example

```
EB64> version  
Wed Feb 10 19:52:24 EST 1993
```

## wabox

The **wabox** command writes to the CPU ABOX\_CTL register.

### Format

**wabox** data

### Parameters

#### data

Specifies the new value written to the register.

### Description

The **wabox** command writes to the CPU ABOX\_CTL register. The motherboard does not check for valid register values.

This command applies only to Alpha motherboards based on the 21064 and 21066 microprocessors.

### Example

```
EB64> wabox  
00000000000000428  
EB64> wabox 418  
EB64> wabox  
00000000000000418
```

## User Commands

### **wb**

### **wb**

The **wb** command writes a byte (8 bits) to a register port in I/O address space.

### **Format**

**wb** register data [iterations]

### **Parameters**

#### **register**

Specifies which register to write to.

#### **data**

Specifies the value that is written to the register.

#### **iterations**

Specifies how many times the data is read. The default is 1.

### **Description**

The **wb** command writes a byte to the specified register in I/O address space.

### **Example**

```
EB64> rb 280  
28  
EB64> wb 280 68  
EB64> rb 280  
68
```



## wbcfg

The **wbcfg** command writes to the backup cache configuration register.

### Format

```
wbcfg bcfg_data [bctl_data]
```

### Parameters

#### **bcfg\_data**

Specifies the new backup cache configuration register value.

#### **bctl\_data**

Specifies the new backup cache control register value. If not supplied, the current value remains unchanged.

### Description

The **wbcfg** command writes to the backup cache configuration register and the backup cache control register in the same command. If you are making a change to the configuration register that requires a change to the control register, specify both values in a single write to prevent the CPU from being in an inconsistent state. If the change you are making to the backup cache configuration register does not require a change to the control register, the second parameter is optional. The memory controller registers are automatically changed to reflect the new state of the backup cache.

This command is implemented only for the Alpha 21164 microprocessor family.

### Example

```
EB164> wbcfg 1e22772 28051
Old BC_CTL = 0x00008051 & BC_CFG = 0x01E21772
New BC_CTL = 0x00028051 & BC_CFG = 0x01E22772
    CIA_CACK_EN = 0x8 & CIA_MCR = 0x0001FE21
```

## User Commands

### wbctl

### wbctl

The **wbctl** command writes to the backup cache control register.

### Format

```
wbctl bctl_data [bcfg_data]
```

### Parameters

#### **bctl\_data**

Specifies the new backup cache control register value. If not supplied, the current value remains unchanged.

#### **bcfg\_data**

Specifies the new backup cache configuration register value.

### Description

The **wbctl** command writes to the backup cache control register and the backup cache configuration register in the same command. If you are making a change to the control register that requires a change to the configuration register, specify both values in a single write to prevent the CPU from being in an inconsistent state. If the change you are making to the backup cache control register does not require a change to the configuration register, the second parameter is optional. The memory controller registers are automatically changed to reflect the new state of the backup cache.

This command is implemented only for the Alpha 21164 microprocessor family.

### Example

```
EB164> wbctl 8051
Old BC_CTL = 0x00028051 & BC_CFG = 0x01E21772
New BC_CTL = 0x00008051 & BC_CFG = 0x01E21772
    CIA_CACK_EN = 0x8 & CIA_MCR = 0x0001FE21
```

## wbiu

The **wbiu** command writes to the CPU BIU\_CTL register.

### Format

**wbiu** data

### Parameters

#### data

Specifies the new value written to the register.

### Description

The **wbiu** command writes to the CPU BIU\_CTL register. The motherboard does not check for valid register values.

**Caution:** Bit 2 of the BIU\_CTL register cannot be cleared with this command. Setting the OE could damage the EB64. If you are writing your own software and accessing the BIU\_CTL register, set bit 2 of this register to 1 to avoid potential damage to your hardware.

This command applies only to motherboard designs based on the Alpha 21064 microprocessor.

### Example

```
EB64> rbiu
0000000E2001C645
EB64> wbiu E2001c545
EB64> rbiu
0000000E2001C545
```

## User Commands

### wiccsr

#### wiccsr

The **wiccsr** command writes to the CPU ICCSR register.

#### Format

**wiccsr** data

#### Parameters

##### data

Specifies the new value written to the register.

#### Description

The **wiccsr** command writes to the CPU ICCSR register. The motherboard does not check for valid register values.

#### Example

```
EB64> riccsr  
000006F800000000  
EB64> wiccsr 6f90000000  
EB64> riccsr  
000006F900000000
```

## wl

The **wl** command writes a longword (32 bits) to a register port in I/O address space.

### Format

**wl** register data [iterations]

### Parameters

#### register

Specifies which register to write to.

#### data

Specifies the value that is written to the register.

#### iterations

Specifies how many times the data is read. The default is 1.

### Description

The **wl** command writes a longword to the specified register in I/O address space.

### Example

```
EB64> wl 370 0000a6f3
```

## User Commands

### wrfen

### wrfen

The **wrfen** command enables or disables floating point.

### Format

**wrfen** value

### Parameters

#### value

Specifies a value of 0 or 1 that is written into the processor's floating-point enable register.

### Description

The **wrfen** (write floating-point enable) command writes bit zero of the value passed to the floating-point enable register in the CPU. The value of FEN is also updated to the PCB.

### Example

```
AlphaPC164> wrfen 1
```

## wsys

The **wsys** command writes to the EB64 system control register.

### Format

**wsys** data

### Parameters

**data**

Specifies a value that becomes the new value of the system register.

### Description

The **wsys** command modifies the contents of the EB64 system register. This command applies only to the EB64.

### Example

```
EB64> rsys  
840000  
EB64> wsys 177700  
EB64> rsys  
177700
```

## User Commands

### **ww**

### **ww**

The **ww** command writes a word (16 bits) to a register port in I/O address space.

### **Format**

**ww** register data [iterations]

### **Parameters**

#### **register**

Specifies which register to write to.

#### **data**

Specifies the value that is written to the register.

#### **iterations**

Specifies how many times the data is read. The default is 1.

### **Description**

The **ww** command writes a word to the specified register in I/O address space. For example, on the EB64, the word is written to the ISA extension slot.

### **Example**

```
EB64> ww 370 4  
EB64> rw 370  
0004
```



# A

---

## Support, Products, and Documentation

If you need technical support, a *DIGITAL Semiconductor Product Catalog*, or help deciding which documentation best meets your needs, visit the DIGITAL Semiconductor World Wide Web Internet site:

**<http://www.digital.com/semiconductor>**

You can also call the DIGITAL Semiconductor Information Line or the DIGITAL Semiconductor Customer Technology Center. Please use the following information lines for support.

<b>For documentation and general information:</b>	
<b>DIGITAL Semiconductor Information Line</b>	
United States and Canada:	1-800-332-2717
Outside North America:	1-510-490-4753
Electronic mail address:	semiconductor@digital.com

<b>For technical support:</b>	
<b>DIGITAL Semiconductor Customer Technology Center</b>	
Phone (U.S. and international):	1-978-568-7474
Fax:	1-978-568-6698
Electronic mail address:	ctc@hlo.mts.dec.com

## DIGITAL Semiconductor Products

**Note:** The following products and order numbers might have been revised. For the latest versions, contact your local distributor.

### Microprocessors

To order Alpha microprocessors, contact your local distributor.

Product	Order Number
DIGITAL Semiconductor Alpha 21164 600 MHz Microprocessor	21164-MB
DIGITAL Semiconductor Alpha 21164 533 MHz Microprocessor	21164-P8
DIGITAL Semiconductor Alpha 21164 466 MHz Microprocessor	21164-IB

### Motherboard Kits

Motherboard kits include the motherboard, the motherboard's user's manual, and firmware.

Product	Order Number
DIGITAL Semiconductor AlphaPC 164SX Motherboard Windows NT	21A05-A0
DIGITAL Semiconductor AlphaPC 164SX Motherboard DIGITAL UNIX	21A05-A1
DIGITAL Semiconductor AlphaPC 164LX Motherboard Windows NT	21A04-C0
DIGITAL Semiconductor AlphaPC 164LX Motherboard DIGITAL UNIX	21A04-C1
DIGITAL Semiconductor AlphaPC 164 Motherboard Windows NT	21A04-B0
DIGITAL Semiconductor AlphaPC 164 Motherboard DIGITAL UNIX	21A04-B2

### Design Kits

Design kits include full documentation and schematics. They do not include motherboards or related hardware.

Design Kits	Order Number
DIGITAL Semiconductor AlphaPC 164 Motherboard Design Kit	QR-21A04-12

## DIGITAL Semiconductor Documentation

The following table lists some of the available DIGITAL Semiconductor documentation.

<i>(Sheet 1 of 2)</i>	
<b>Title</b>	<b>Order Number</b>
Alpha AXP Architecture Reference Manual <sup>1</sup>	EY-T132E-DP
Alpha Architecture Handbook <sup>2</sup>	EC-QD2KB-TE
DIGITAL Semiconductor 21164PC Alpha Microprocessor Hardware Reference Manual	EC-R2W0A-TE
DIGITAL Semiconductor 21164 Alpha Microprocessor Hardware Reference Manual	EC-QP99B-TE
DIGITAL Semiconductor AlphaPC 164SX Motherboard Product Brief	EC-R57CA-TE
DIGITAL Semiconductor AlphaPC 164LX Motherboard Product Brief	EC-R2RZA-TE
AlphaPC 164SX Motherboard Windows NT User's Manual	EC-R57DA-TE
AlphaPC 164LX Motherboard Windows NT User's Manual	EC-R2ZQD-TE
DIGITAL Semiconductor AlphaPC 164LX Motherboard Technical Reference Manual	EC-R46WA-TE
DIGITAL Semiconductor AlphaPC 164 Motherboard Product Brief	EC-QUQKC-TE
AlphaPC 164 Motherboard User's Manual	EC-QPG0B-TE
DIGITAL Semiconductor AlphaPC 164 Motherboard Technical Reference Manual	EC-QPFYB-TE
DIGITAL Semiconductor AlphaPC 164 Motherboard Design Kit Read Me First	EC-QPFZA-TE
DIGITAL Semiconductor AlphaPC 164 Motherboard DIGITAL UNIX Product Brief	EC-QZT6B-TE
AlphaPC 164 Motherboard DIGITAL UNIX User's Manual	EC-QZT5B-TE
DIGITAL Semiconductor Alpha Motherboards Software Developer's Kit and Firmware Update V3.1 Product Brief	EC-QXQKC-TE
Alpha Motherboards Software Developer's Kit and Firmware Update Read Me First	EC-QERSH-TE
Alpha Microprocessors Motherboard Software Design Tools User's Guide	EC-QHUWD-TE

<i>(Sheet 2 of 2)</i>	
<b>Title</b>	<b>Order Number</b>
Alpha Microprocessors Motherboard Windows NT 3.51 and 4.0 Installation Guide	EC-QLUAH-TE
Alpha Microprocessors SROM Mini-Debugger User's Guide	EC-QHUXC-TE
Alpha SRM Console for Alpha Microprocessor Motherboards User's Guide	EC-QK8DF-TE
PALcode for Alpha Microprocessors System Design Guide	EC-QFGLC-TE

<sup>1</sup> To purchase the *Alpha AXP Architecture Reference Manual*, contact your local distributor or call Butterworth-Heinemann (Digital Press) at 1-800-366-2665.

<sup>2</sup> This handbook provides information subsequent to the *Alpha AXP Architecture Reference Manual*.

### Third-Party Documentation

You can order the following third-party documentation directly from the vendor.

<b>Title</b>	<b>Vendor</b>
PCI Local Bus Specification, Revision 2.0 PCI Local Bus Specification, Revision 2.1 PCI BIOS Specification, Revision 2.1	PCI Special Interest Group 1-800-433-5177 (U.S.) 1-503-797-4207 (International) 1-503-234-6762 (Fax)

---

# Index

## A

---

Alpha, 1–2  
    documentation, A–3  
Alpha SRM Console firmware, 2–11  
AlphaBIOS, 2–7  
apropos, 4–11  
arpshow, 4–12  
Audience, ix

## B

---

Baud rate, 2–1  
bcoeff, 4–13  
bcon, 4–14  
beep, 4–15  
boot, 2–4, 4–16  
Boot address, 4–17  
bootadr, 4–17  
bootopt, 4–18  
BOOTP, 4–96  
BOOTP server  
    setting up, 2–4  
    verification of, 2–5  
bootptab, 4–96, 4–98  
bpstat, 4–20

## C

---

cb, 4–21  
cfreg, 4–22  
cl, 4–24  
Command features, 1–1  
Command interface features, 4–1  
Command line editing, 4–1  
Command overview, 4–1  
Command quick reference, 4–4  
Commands  
    usage of, 4–2  
Communication ports, 2–1, 2–3  
compare, 4–25  
Configuring the system, 2–1  
Connecting to a PC, 2–2  
Connecting to a serial port, 2–4  
Connecting to a system for DIGITAL UNIX,  
    2–3  
Connecting to a system for Windows NT, 2–2  
Connecting to a terminal, 2–1  
Connector J12, 2–1  
cont, 4–26  
Conventions of document, x  
copy, 4–27  
cq, 4–29

creg, 4-31

cw, 4-33

## D

---

Daemon log file, 2-5

date, 4-35

Debug Monitor commands, 4-10

Debugger

definition of, 3-1

Debugging hints, 3-1

delete, 4-36

Digital Semiconductor Information Line, A-1

DIGITAL UNIX, 1-2, 2-3

DIGITAL UNIX remote debugging, 3-1

DIGITAL UNIX tip command, 2-4

dis, 4-37

Diskette, 2-18

DMA buffers, 2-18

dml, 4-39

dmq, 4-40

Document

audience, ix

conventions, x

structure, x

Documentation, A-3

Downloading files, 2-18

Drive, 4-61, 4-65

## E

---

ebuff, 4-41

edevic, 4-42

edmp, 4-43

einit, 4-44

eml, 4-45

emq, 4-46

Environment for PALcode, 3-3

eprom, 4-47

ereg, 4-48

eshow, 4-50

estat, 4-51

estop, 4-52

Ethernet, 2-18

Execution commands, 2-18

## F

---

Features, 1-1

of command interface, 4-1

fill, 4-53

Firmware update

Alpha SRM Console firmware, 2-11

AlphaBIOS, 2-7

Debug Monitor, 2-10

Windows NT ARC, 2-9

Firmware update utility, 2-5

flash, 4-55

Flash ROM, 2-6

flasher, 4-58

flboot, 4-60

flcd, 4-61

flcopy, 4-63

fldir, 4-65

flload, 4-67

flread, 4-68

flsave, 4-70

flwrite, 4-71

fwupdate, 4-73

fwupdate.exe, 2-6

## G

---

Getting started, 2-1

go, 2-18, 4-74

## H

---

Hardware requirements, 2-1  
help, 4-75  
Host system, 2-4

## I

---

iack, 4-77  
ident, 4-78  
init, 4-80  
Introduction, 1-1

## J

---

jtopal, 2-18, 4-81

## K

---

Kernel stack, 2-17

## L

---

Ladebug, 2-5, 3-1  
    command line options, 3-4  
    starting a session, 3-6  
ladebug command, 4-82  
load, 2-4, 4-84  
Loading a file  
    from diskette, 4-60, 4-67  
Loading a program, 2-18

## M

---

Machine check, 4-86  
mces, 4-85  
mcheck, 4-86  
Memory map, 2-16  
Memory regions, 2-18  
memtest, 4-88  
mrb, 4-90  
mrl, 4-91

mrw, 4-92  
mwb, 4-93  
mwl, 4-94  
mww, 4-95

## N

---

netboot, 2-4, 4-96  
netload, 2-4, 4-98  
next, 4-100

## O

---

Operating system requirements, 2-1  
Ordering products, A-2

## P

---

PALcode environment, 3-3  
PALcode guidelines, 3-3  
Path, 4-61, 4-65  
pb, 4-102  
PC  
    connecting to, 2-2  
pcishow, 4-104  
Personal computer, 2-2  
pfgreg, 4-106  
pl, 4-107  
pq, 4-109  
prb, 4-111  
preg, 4-112  
prl, 4-113  
Products  
    ordering, A-2  
Programmable memory regions, 2-18  
prw, 4-114  
pw, 4-116  
pwb, 4-118

pwl, 4-119  
pww, 4-120

## R

---

rabox, 4-121  
rb, 4-122  
rbcfg, 4-123  
rbctl, 4-124  
rbiu, 4-125  
Recommended host system, 1-2  
Related documentation, A-3  
Remote debug server, 3-1  
Remote debugger  
    definition of, 3-1  
Remote debugging, 2-5, 3-1  
    command line options, 3-4  
    executable file, 3-5  
    guidelines, 3-2  
Requirements  
    host system, 2-1  
Reset, 2-19  
riccsr, 4-126  
rl, 4-127  
rmode, 4-128  
romboot, 4-131  
romlist, 4-134  
romload, 4-135  
romverify, 4-138  
rsys, 4-140  
rw, 4-141

## S

---

sb, 4-142  
Serial connection - DIGITAL UNIX, 2-3  
Serial port, 2-1, 2-18, 4-16  
    connecting to, 2-4  
setbaud, 4-144

Setting up for remote debugging, 2-5  
setty, 4-145  
sl, 4-146  
sq, 4-148  
Stack, 2-17  
step, 4-150  
stop, 4-152  
Structure of document, x  
sum, 4-153  
Summary of commands, 4-4  
sw, 4-154  
swpipl, 4-155  
sysshows, 4-156  
System configuration, 2-1

## T

---

Technical support, A-1  
Terminal  
    connecting to, 2-1  
tip, 4-157  
    DIGITAL UNIX command, 2-4

## U

---

Updating firmware, 2-5  
User commands, 4-10  
UVPRO, 2-6

## V

---

version, 4-158

## W

---

wabox, 4-159  
wb, 4-160  
wbcfg, 4-161  
wbctl, 4-162



wbiu, 4-163  
wiccsr, 4-164  
Windows NT, 1-2, 2-2  
wl, 4-165  
wrfen, 4-166  
wsys, 4-167  
ww, 4-168